



INSTRUCTION MANUAL




Please read the Manual carefully before operation. If the parts were missed or damaged, do not return it first.

Instructions


1. Take out the compressed pack from the box.




After removing the sofa from the bag, please cut the bag into pieces to prevent children from playing with it.




2. Cut open the plastic bag with a scissors and remove the bag.



3. Let the chair stay decompressing for 48-72 hours.



4. The chair will fully recover to its shape and then can be seated.



Please make sure you are aware of our sofas, you will not be able to put the sofa in the box once the compression bag has been opened. We are unable to provide a returnable box.

CONTACT US!

DO NOT return this product

Contact our friendly customer service team first for help.

