


Assembly Instructions




ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

No Tools Required For Assembly

EASY



DIFFICULT




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.



Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#1 x 1pc
Top Glass




#2 x 1pc
Bottom Glass



#3 x 1PC
Bottom Panel



#4 x 4pcs
Cover



#5 x 4pcs
Support Panel



#6 x 4pcs
Leg Panel



#7 x 4pcs
Iron Ball



#8 x 4pcs
Upper Cover

Parts List



#9 x 4pcs
Lower Cover

Hardware List



#A x 4pcs
Bolt 1/4"x18mm



#B x 4pcs
Suction Cup



#C x 4pcs
Large Suction Cup




#D x 4pcs
Bolt 1/4"x82mm



#1

#A x 4pcs

2. Insert a stud bolt (#A) into the bottom end of each, turn right to tighten.



1. Insert the support panels (#5) into the bottom panel (#3).


3. Apply the legs (#6) onto the other ends of the stud bolts, turn right to tighten.



#2

#C x 4pcs
#D x 4pcs

1. Align the cover (#4) to the top of the support panel (#5), then insert the bolt (#D).





2. Place the bottom glass (#2) onto the bolt, then place the lower cover (#9), upper cover (#8), and the iron ball (#7). Turn to tighten.

3. Place the large suction cups (#C) onto the bottom ends.



#B x 4pcs

Place the suction cups (#B) onto the balls, then place the top glass (#1) onto those suction cups.



ASSEMBLY IS COMPLETED