

NO ASSEMBLY REQUIRED

Pro Tip: The sofa may feel compact or uneven initially. This is normal! Give it 72 hours to fully expand and regain its shape. Fluff the cushions gently to speed up the process.

