

Assembly Instructions

Caution: You must read this before you proceed.

Care & Maintenance



● Not for commercial use. For residential use only.



● Furniture may scratch floors. We recommend using furniture pads to protect your floors.



● Do not put hot items directly on furniture surface.



● Do not clean furniture with harsh cleansers or polish.



● Do not place furniture under direct sunlight.



● Do not place furniture near heating or cooling vents.



● Do not write on furniture without a padded barrier to protect the surface.



● Do not place furniture outside . For indoor use only.



● Stains may be removed with mild soap solution and damp cloth.



● Children should not climb or jump on the furniture.




● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Carton for hardware packs and legs.




Sets often ship in multiple boxes and may arrive a day or two apart.

Dining Chair



Caution: This Dining Chair is NOT a TOY.
Keep your child / children at bay during the assembly process.
Whenever moving or lifting the Dining Chair and to prevent any possible damage to it, two adults are needed to execute this action.

Parts List

Label	Picture	Description	Qty
A		Back Leg	1
B		Front Leg	1
C		Seat panel	1




HARDWARE

Label	Picture	Description	Qty
1		Bolts 1/4" x 80mm	8+1
2		Bolts 1/4" x 35mm	4+1
3		Spring washer	12+1
4		Flat Washer	12+1
5		Wrench	1

Hardware : Each of the above hardware including extra 1 pc

Assembly Preparation

Before beginning assembly



 ① x9

 ② x5

 ③ x13

 ④ x13

 ⑤ x1



- Read instruction, cover to cover.



- Have 2 adults on hand for assembly.



- Do not assemble on flooring or carpet.




- Assemble on a clean non-marring surface (packing foam).



- Save all packaging until finished.


Assembly Steps

Overview



This Dining Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Dining Chair parts, the above picture is to help you put the various Dining Chair parts into perspective. Please read through the instructions here below to familiarise the parts and steps before assembly.



STEP 1



Unpack and place all parts on a clean, non-marring surface.


STEP 2

2x4	3x4	4x4	5x1




Attach the Back Leg (A) and Front Leg (B) to the Seat panel (C) using Flat Washers (4), Spring Washers (3), Bolt (2), Wrench (5) as shown below. Please non full tighten bolt

STEP 3




1x8	3x8	4x8	5x1

Attach Flat Washers (4), Spring Washers (3), Bolt (1), Wrench (5) as shown below. Please non full tighten bolt



STEP 4




① If wobble




③

Test again




②



30 - 50cm



LEVELER



Note: Front/Back legs can be adjusted with adjustable levelers.



- Place the Dining Chair on a Level Surface to check if it wobbles.

If it wobbles, lift the Dining Chair up some 30cm to 50cm from the ground, keep your feet and toes well away from the drop zone, and drop the Dining Chair freely and vertically with the four legs, hitting the ground at the same time.

This Drop Test will help ensure that all parts and gaps reach full alignment. Test again for evenness on a Level Surface. If no wobbles are found, proceed to tighten all the Bolts.

When tightening the Bolts, tighten sequentially.

Do not tighten any Bolt fully and then move on to the next one, as this could cause the frame to warp. Rather in a sequential manner, gradually tighten each Bolt until all are evenly secured. This methodology will ensure maximum evenness once all Bolts are fully tightened.

If the chair still wobbles, loosen the Bolts and execute the same drop test, then proceed to tighten the bolts again in a sequential manner.

- Ensure all screws are fully locked into position.

The Dining Chair is ready to be used.

Caution 2: This Dining Chair can only be used on a flat, level surface

Questions & Answers about Proposition 65

● What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

● What types of chemicals are on the Proposition 65 list? The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust.

● What does a warning mean?

If a warning is placed on a product label or posted or distributed at a workplace, a business, or in rental housing, the business issuing the warning is aware or believes that it is exposing individuals to one or more listed chemicals.

By law, a warning must be given for listed chemicals unless the exposure is low enough to pose no significant risk of cancer or is significantly below levels observed to cause birth defects or other reproductive harm.

● Where can I get more information on Proposition 65?

If you have specific questions on the administration or implementation of Proposition 65, you can contact OEHHA's Proposition 65 program at P65.Questions@oehha.ca.gov, or by phone at (916) 445-6900.