


ACCESSORY PRODUCTS




SEAT



BACKREST



HEADREST



HANDRAIL



ALLEN KEY



FIVE CLAW TRIPOD



AIR PRESSURE ROD



CASTER WHEELS*5




SCREW*4



SHIM*4



ZHONGGUI LINE



POWER LINE



EXTENSION

Precautions

Please read this guide carefully before using the product and save it for future use; Please refer to the relevant website for detailed product usage guidelines;

1. Operating environment: -20 °C-60 °C. Before use, please check if all power cords are securely connected;
2. Check if the surrounding environment is safe and ensure that there are no obstacles within the range of the office chair lying flat;
3. Charging voltage: Input AC 100-240V frequency 50/60HZ; Output DC 29.4V;
4. If the power cord is damaged, do not attempt to repair it yourself. Instead, seek professional replacement or repair to avoid injury;

INSTRUCTIONS




- A. Ventilation button
- B. Heating button
- C. 5V+USB output D29V - charging socket
- E. Chair body reset button
- F. Chair body unfolding button



INSTALLATION STEPS


step 1

Insert the wheels one by one into the five claw tripod, and insert the pneumatic rod into the center hole of the five-star tripod.



step 2

Align the air rod on the tripod with the center hole of the chair seat and insert it.




step 3

1. Connect the power cord between the seat and backrest.
2. Insert the backrest diagonally into the latch of the seat to make it fit. Step
3. Insert the headrest into the hole above the backrest to make it fit.



step 4

1. Hold the position of the finger, fix the armrest, and screw it vertically and smoothly into the screw hole at point A.
2. After fixing the screw hole at point A, adjust the handrail and screw it vertically and manually into the screw hole at point B.
3. Finally, use a hex wrench to tighten the screws.



Use safety reminders



Please do not bounce or play on the chair.



When opening the chair, please confirm if there are any obstacles around the chair



Please do not sit alone at the head or tail of the sofa.



Do not stand up directly when the chair is in an unfolded state.

step 4

Attention: The raised parts of armrests A and B belong to the inner side facing towards the chair as shown in Figure 1.