




CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
The use of steam or water-based cleaners may cause excessive shrinking or staining.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Arm		2X
H1	Allen bolt		12X
H2	Spring washer		12X
H3	Flat washer		12X
H4	Allen key		1X

Product Dimensions:58.27" W x27.95" D x27.56" H



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package content list and hardware content list. If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 30 minutes.
Tools Required for Assembly (included): Allen Key

