

# FLOOR LAMP

## ASSEMBLY INSTRUCTIONS

These instructions are provided for your safety.  
Please read carefully before commencing work and retain for future reference.

### SAFETY INFORMATION

- \* The supply cable runs through the inside of this product. Take care not to place undue stress on the cable whilst unpacking to prevent the possibility of a poor connection.
- \* If you are in any doubt consult a person competent to give advice on the assembly of electrical equipment.
- \* Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Do not exceed wattage stated.
- \* If the external flexible cable of the lamp is damaged it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- \* To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instructions before assembly.
- \* When changing the bulb, always unplug from the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

### ASSEMBLY INSTRUCTIONS

1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
2. Lay the product out on the floor. If the floor is not carpeted please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat.
3. It may be necessary to remove protective packaging (plastic / cardboard) located at cable entry points of the product.
4. Screw the main stem onto the top section of the light by rotating the stem only – take care not to twist the wiring. (1)
5. Fit the lower part of the stem through the base (2) fit the washer and nut and tighten (3).
6. Stand the floor lamp upright and ensure all the assembled parts are fully tightened.
7. Fit the adjustment handle by screwing it into the neck of the lighting head (4)
8. Unscrew the clips retaining the glass cover in place and carefully remove the glass placing to one side. Fit bulb: type and wattage as indicated on fitting. **The wattage indicated must not be exceeded.** Carefully re-fit the glass and tighten the retaining clips to secure. Do not overtighten the clips as damage may occur. The glass should not be tight to allow expansion and contraction of the glass when it heats and cools.
9. Floor lamp is now ready for use.

