


ASSEMBLY INSTRUCTIONS


- Caution:** Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staple used in packing.
1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 3. please do not over tighten screws or bolts.
 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.




HARDWARE LIST							
PARTS	DESCRIPTION	SKETCH	QTY	PARTS	DESCRIPTION	SKETCH	QTY
A	ALLEN KEY		1PC	G	UCBC BOLT Ø1/4" x 1 1/2"		4PCS
B	UCBC BOLT Ø1/4" x 3 1/4"		8PCS				
C	SPRING WASHER Ø1/4"		12PCS				
D	FLAT WASHER Ø1/4"		12PCS				
E	UWASHER Ø1/4"		8PCS				
F	Screw Ø8 x 1-1/4"L		16PCS				

PART LIST							
PARTS	DESCRIPTION	SKETCH	QTY	PARTS	DESCRIPTION	SKETCH	QTY
(1)	HEADBOARD PANEL		1PC	(6)	FRUNDLE SIDE PANEL		2PCS
(2)	FOOTBOARD PANEL		1PC				
(3)	BOTTOM RAIL		2PCS				
(4)	SIDE RAIL		2PCS				
(5)	FRUNDLE FRONT PANEL		2PCS				

STEP1




STEP2




ASSEMBLY INSTRUCTIONS


STEP3



STEP4



STEP5



STEP6

