


4 Door Sideboard






Instruction
Manual

Read Before Assembly

The instruction booklet contains **IMPORTANT** safety information. Please read it in full and keep it for future reference.





WARNING!



- Serious or fatal cushion injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.
- Different wall materials requires different type of wall anchors or screws. Use a suitable wall anchors or screws for your specific wall in order to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of device to use, please contact us or local hardware store and seek professional advice.
- Only place items that is within the recommended size and weight limit of the furniture.
- Items placed onto the furniture must be resting on a support surface without hanging over the edges.
- Climbing on, stepping on, or placing overweighted objects on the product may cause property damage and / or injuries.



CAUTION!



- Assemble the furniture on an empty carton, carpet, or rug to prevent scratches or damage.
- When assembling the furniture, keep pets and children away from the assembly area.
- Ensure the product is fully assembled before use. If you are missing any hardware or parts, do not use it until you have restored the missing parts.
- This furniture requires 2 people for assembly.
- Lay out all components and hardware separately on a flat surface and make sure that no parts are missing or damaged before assembly. Do not destroy or discard any packaging until you are certain that you have all the necessary parts for assembly.
- There are small components used in the construction of the furnitures. Loose items, plastic bags, and packaging films should be kept away from pets or children to avoid choking hazard or suffocations.
- Read this instruction manual prior to assembly and familiarize yourself with the various steps.
- Install all hardware perpendicular to the opening unless otherwise specified.
- Hand tight all hardware and careful not to over-tighten to avoid damaging the product.

Assembly Symbols



- Follow sequential order.



- Build specified number of parts.



- Flip part as indicated.



- Rotate part as indicated.



- Choose your own assembly options.



- Pay attention to the part orientation.



- Leave bolts or screws partially tighten.



- Fully tighten bolts or screws.



- Level the furniture on the ground.




Estimated Time for Assembly


100 mins




Weight Capacity Limitations are as Follows:




Tools Needed



• Philips Screwdriver




• Rubber Mallet Hammer



• Electric Drill








Package Contents



Package Contents

CODE	DESCRIPTION	QTY
1	Top Panel	1
2	Bottom Panel	1
3	Left Lateral Panel	1
4	Right Lateral Panel	1
5	Upper Back Panel	1
6	Bottom Back Panel	1
7	Crossbar	2
8	Storage Shelf Panel	2
9	Medial Panel	1
10	Cabinet Door	1
11	Cabinet Door	1
12	Cabinet Door	1
13	Cabinet Door	1

Package Contents



Package Contents

R



2x

S



ø3 x 12 mm


4x

T



4x

U



8x



V





ø6 x 30 mm

4x

01 Back panels



02 Back panels




*Assembly symbols





Pay attention to part orientation

03 Back panels





V 4x




04 Top and bottom panels



A 8x




05 Attaching magnetic catches




M 2x




N 8x





06 Top and bottom panels





E 12x



07 Assembling top panel to upper back panel





08 Assembling bottom panel to the bottom back panel




09

Medial Panel



10

Medial panel and crossbars





*Assembly symbols



Flip part as indicated



11

Assembling crossbars to the medial panel





12

Assembling the top half of the carbinet





13

Connecting the top assembly to the bottom





14

Lateral panels





15

Assembling lateral panels to the cabinet assembly






16

Attaching support legs




17

Securing back panels




18

Attaching shelf pegs and putting on shelf panels



U 8x



19


Attaching catch plates on cabinet doors



S 4x




T 4x



20 Attaching door hinges to cabinet doors




F 8x




H 4x


i



G



H




21

Attaching cabinet doors to the center of the cabinet



F 16x




22 Attaching door hinges to cabinet doors



F 8x




G 4x







23 Attaching cabinet doors to the cabinet









F 16x



i







Loosen the screws on the mounting plate to adjust the door **up and down**.







Adjust the screw on the hindege to microadjust the door from **side to side**.

Loosen the screws on the hinge arm to adjust the door **in and out**.



i



Loosen the screws on the mounting plate to adjust the door **up and down**.




Adjust the screw on the hindge to microadjust the door from **side to side**.



Loosen the screws on the hinge arm to adjust the door **in and out**.

24

Rebound hinge, only need to gently press the doorpanel when opening the door.



25


Attaching anti-tipping straps





O 2x



P 2x



26 Affixing cabinet to a wall



- Series or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently affixed to the wall with anti-tipping device(s) in order to prevent the furniture from tipping over.

*Assembly symbols

1

2

Follow sequential order

Care and Maintenance

Thank you for your purchase. We want your item to last as long as possible.

To ensure the product gives you years of longevity, please follow the recommendations in this care and maintenance guide.



Maintenance

- Tighten all bolts and crews again within the first 2 weeks of assembly.
- Check the tightness of all bolts every 2 months and retighten them if they come loose.



Cleaning

- Clean the surface of the MDF (medium density fiberboard) with a lightly dampened cloth.
- A small amount of mild soap can be used if necessary.
- Dry the surface immediately after cleaning.



Attention

DO NOT use bleach or alcohol based cleaner to clean the surface.

DO NOT apply wood treatment on parts made with MDF.

MDF will swell and distort when exposed to water damage.

Make sure to dry the furniture immediately after cleaning.



Attention

The manufacturer and seller are not responsible for any and all liability relating to personal injury, property damage or losses, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification or neglect of this product.