







Outdoor Wicker Glass Top Table



PART LIST


 Top Panel		 Side Panel	
A	1PC	B	2PCS
 End Panel		 Glass Top	
C	2PCS	D	1PC

HARDWARE LIST


 Bolt(M6*30mm)		 Washer(M6mm)		 Allen Key(M6mm)	
E	12PCS	F	12PCS	G	1PC
EXTRA HARDWARE LIST					
 E X3PCS		 F X3PCS			

Step 1. Lay Top Panel (A) on a flat surface with underside facing up. Attach Side Panels(B) to Top (A), using Bolts(E), Washers(F) and Allen Key (G).

NOTE:Thread down but do not tighten bolts until unit is fully assembled.



Step 2. Attach End Panels (C) to Side Panels (B) using Bolts(E), Washers(F) and Allen Key(G).



Step 3. Turn the table upright and gently place the glass on the table top.

