
## **ASSEMBLY INSTRUCTIONS ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishment.




Α

В

С

G



PAGE 2 OF 5

COASTERFURNITURE.COM

- 1. Remove hardware from box and sort by size.
- 2 . Please check to see that all hardware and parts are present prior to start of assembly.
- 3 . Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# $\mathbb{A}$

#### WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2 . This product is for home use only and not intended for commercial establishment.



### ASSEMBLY TIME

HARDWARE IDENTIFICATION

**30 MINUTES** 

## Z-B1 (BOX1) - HARDWARE PACK IS LOCATED IN 204391KE (B1)

1	BOLT (M6 x30mm - BLK)		6PCS	4 FLAT HEAD SCREW (M4 x 32mm - RBW)	Ammin	8PCS
2	LOCK WASHER (1/4" - BLK)	Ø	6PCS	5 SMALL ALLEN WRENCH (M4 x 65mm - BLK)		1PC
3	FLAT WASHER (1/4" x13mm - BLK)	0	6PCS	6 BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC

#### NOTE:

Philips head screw driver in the assembly process ; however, manufacturer does not provide the item

PAGE 3 OF 5

