ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED

Screwdriver
(Not included)



Allen Wrench

2 - People

ASSEMBLY RATING



EASY ► D.FFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION# 25-10-24

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.

Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.

Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.

Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.

Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

Q BED



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PART

① 1 pc



HEADBOARD

② 1 pc



HB - LEG RIGHT

③ 1 pc



HB - LEG LEFT

④ 1 pc



FOOTBOARD

⑤ 2 pcs



SIDE RAIL

⑥ 4 pcs



SLAT
1540 x 42 x 17mm

⑦ 4 pcs



VERTICAL LEG
219 x 29 x 29

⑧ 1 pc



HEADBOARD STRETCHER

HARDWARE

HARDWARE INSIDE HEADBOARD / FOOTBOARD / SLAT / VERTICAL LEG / HB STRETCHER.

Ⓐ 6 pcs

Bolt M8x40mm

Ⓑ 6 pcs

Lock Washer
M8

Ⓒ 14 pcs

Flat Washer
M8

Ⓓ 1 pc

Allen Key M5

Ⓔ 1 pc

Adapter

Ⓕ 8 pcs

Bolt M8x20mm

Ⓖ 8 pcs

Panhead screw
M4x30mm

Ⓗ 4 pcs

Bolt M6x35mm

Ⓘ 4 pcs

Lock Washer
M6

Ⓙ 4 pcs

Flat Washer
M6

Ⓚ 1 pc

Allen Key M4

CARTON	DESCRIPTION	PART	HARDWARE
	QUEEN HEADBOARD	1 x 1	A x 6 PCS
			B x 6 PCS
	QUEEN HB - LEG RIGHT	2 x 1	 C x 14 PCS
			D x 1 PC
	QUEEN HB - LEG LEFT	3 x 1	E x 1 PC
	QUEEN FOOTBOARD	4 x 1	F x 8 PCS
			G x 8 PCS
	QUEEN SLAT	6 x 4	H x 4 PCS
	QUEEN VERTICAL LEG	7 x 4	I x 4 PCS
			J x 4 PCS
	QUEEN HB STRETCHER	8 x 1	K x 1 PC
	QUEEN/KING SIDE RAIL	5 x 2	

ASSEMBLY INSTRUCTIONS

1

Part ① 1 pc
Part ② 1 pc
Part ③ 1 pc
Hardware Ⓐ 6 pcs
Hardware Ⓑ 6 pcs
Hardware Ⓒ 6 pcs
Hardware Ⓓ 1 pc

Use Allen Key (#D) to attach the HB Leg Right (#2) and HB Leg Left (#3) to the Headboard (#1) by using Bolt (#A) with lock washer (#B) and flat washer (#C)



2

Part ②
Part ③
Part ⑧
Hardware Ⓗ 4 pcs
Hardware Ⓘ 4 pcs
Hardware Ⓙ 4 pcs
Hardware Ⓚ 1 pc



Attached HB Stretcher (#8) and (Use Allen Key (#K) to attach the HB Leg Right (#2) and HB Leg Left (#3)by using Bolt (#H) with lockwasher (#**I**) and flat washer (#J)

ASSEMBLY INSTRUCTIONS

3

Part ④ 1 pc
Part ⑤ 2 pcs
Hardware Ⓕ 8 pcs
Hardware Ⓒ 8 pcs
Hardware Ⓓ 1 pc

Use Allen Key (#D) to attach the Side rail (#5) to Headboard (#1) and Footboard (#4) by using Bolt (#F) with flat washer (#C).



4

Part ⑥ 4 pcs
Part ⑦ 4 pcs
Hardware Ⓔ
Hardware Ⓖ

Attach Adapter (#E) to Headboard (#1)







Attached Vertical Leg (#7) spread slat evenly in to Side Rail (#5) and secure by using Panhead Screw (#H).Tighten with Screw Driver.



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface.If the product wobbles or feels loose. double-check all bolts and for screw are properly tightened and secured

✓ Keep this handy!
Please retain the instruction manual and any order-related information for future reference.

✓ Lift, don't drag!
To avoid damage to product please always LIFT the product when transporting of adjusting the placement

This product is intended for RESIDENTIAL USE ONLY and not to commercial use.

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED

Screwdriver
(Not included)



Allen Wrench

2 - People

ASSEMBLY RATING



EASY ► D.FFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION# 25-10-24

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.

Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.

Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.

Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.

Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.





PART

① 1 pc



NIGHTSTAND

HARDWARE

Ⓐ 1 pc



Adaptor

ASSEMBLY INSTRUCTIONS

1



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface.If the product wobbles or feels loose, double-check all bolts and for screw are properly tightened and secured

Keep this handy!

Please retain the instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement

This product is intended for RESIDENTIAL USE ONLY and not to commercial use.

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED

Screwdriver
(Not included)



Allen Wrench

2 - People

ASSEMBLY RATING



EASY ► D.FFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION# 25-10-24

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**
  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**
  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**
  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**
  Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.

Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.

Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.

Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.

Save the instructions and store any supplied tools for later maintenance.

After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DRESSER



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PART

① 1 pc



DRESSER

HARDWARE

Ⓐ 1 pc



Tip Restraint

ASSEMBLY INSTRUCTIONS

1



Use the tip resistant kit to mount Back of chest (#1) to the wall



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface.If the product wobbles or feels loose. double-check all bolts and for screw are properly tightened and secured

Keep this handy!

Please retain the instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement

This product is intended for RESIDENTIAL USE ONLY and not to commercial use.

ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED

Screwdriver
(Not included)



Allen Wrench

2 - People

ASSEMBLY RATING

EASY ► D.FFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION# 25-10-24

CHECK BEFORE STARTING

- [ ] **Are you missing anything?**

  Double-check all parts, hardware and accessories listed are all acccounted for.

- [ ] **Should we send any replacements?**

  Are there any irregularities or flaws in the parts? We can send replacements!

- [ ] **Check out our Quick Tips!**

  We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

- [ ] **Prep Time!**

  Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.

Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE

FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.

Position each part correctly and insert screws or bolts into their respective holes.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.

Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.

Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

MIRROR





PART

① 1 pc



MIRROR

② 2 pcs



MIRROR SUPPORT

③ 1 pc



DRESSER

HARDWARE

HARDWARE INSIDE MIRROR

Ⓐ 8 pcs



BOLT M6x35mm

Ⓑ 8 pcs

Lock Washer

Ⓒ 8 pcs



Flat Washer

Ⓓ 1 pc



Allen Key M4

is assembly within 2 items

CARTON	DESCRIPTION	PART	HARDWARE
	MIRROR MIRROR SUPPORT	1  x 1 2 x 2	A x 8 PCS B x 8 PCS C x 8 PCS D x 1 PC
	DRESSER VERTICAL LEG	3 x 1 4 x 1	

ASSEMBLY INSTRUCTIONS

1

Part ① 1 pc
Part ② 2 pcs
Hardware Ⓐ 4 pcs
Ⓑ 4 pcs
Ⓒ 4 pcs
Ⓓ 1 pc

Attach the mirror support (#2) to the mirror (#1) by using the screw (#A,B,C,D)



2

Part ③ 1 pc
Hardware Ⓐ 4 pcs
Ⓑ 4 pcs
Ⓒ 4 pcs
Ⓓ 1 pc

Attach the bottom holes of the mirror support (#2) to the dresser (#3) by using the screw (#A,B,C,D)



ASSEMBLY COMPLETED

Please ensure the furniture rests on an even and flat surface.If the product wobbles or feels loose, double-check all bolts and for screw are properly tightened and secured

Keep this handy!
Please retain the instruction manual and any order-related information for future reference.

Lift, don't drag!
To avoid damage to product please always LIFT the product when transporting of adjusting the placement

This product is intended for RESIDENTIAL USE ONLY and not to commercial use.