


# ASSEMBLY INSTRUCTION


## DINING TABLE

DO NOT FULLY TIGHTEN BOLTS UNTIL THE ENTIRE ITEM IS COMPLETELY ASSEMBLED


**A=1PC**




**B=1PC**



**C=2PCS**




**D=1PC**




**E=2PCS**




| No. | Description.              |                                                                                       | Q.Ty          |
|-----|---------------------------|---------------------------------------------------------------------------------------|---------------|
| 1   | <b>BOLT Ø 1/4" x 45mm</b> |     | <b>10 Pcs</b> |
| 2   | <b>FLAT WASHER</b>        |    | <b>10 Pcs</b> |
| 3   | <b>SPRING WASHER</b>      |   | <b>10 Pcs</b> |
| 4   | <b>BOLT Ø 1/4" x 45mm</b> |   | <b>4 Pcs</b>  |
| 5   | <b>ALLEY KEY</b>          |  | <b>1 Pcs</b>  |


### STEP 1




## STEP 2



## STEP 3



## STEP 4



## COMPLETTELY

