


ASSEMBLY INSTRUCTION
SKU CODE: (H10027)





SAFETY WARNINGS



1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk.

Upper bed			
Bed Type	Length	Width	Thickness
Full Standard	74"-75"	53 1/2"	6" max

2. Replacement parts, including additional guardrails, maybe obtained from any of our (MINH HANH IMPORT-EXPORT COMPANY LIMITED) dealers.
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part
11. Use of a night light may provide added safety precaution for a child using the upper bunk..
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited
14. STRANGULATION HAZARD - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes
15. Keep these instruction for future reference
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.




SAFETY WARNINGS
















1. At the beginning :
Tighten all hardware.
Check metal parts for rust. If found, sand and repaint using a non-lead-based paint meeting the requirements of 16 CFR 1303.
Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.
Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
2. Twice a month
Tighten all hardware.
Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.
3. Owners shall be responsible for maintaining the legibility of the warning labels.
4. Disposal Instructions-
There shall be instructions advising the owner to disassemble and dispose of the playground equipment in such a way that no unreasonable hazards will exist at the time the playground equipment is discarded.
5. The instructions shall also include the information found in Section 4 of the United States Consumer Product Safety Commission's (USCPSC) Outdoor Home Playground Safety Handbook or specific guidelines for the product consistent with the USCPSC Handbook. A copy of this section may be found in Appendix X2.
6. Observing the following statements and warnings reduces the likelihood of serious or fatal injury.
7. Specifying the number and weight of occupants that may safely use the equipment singly or simultaneously.
8. Recommending on-site adult supervision for children of all ages,
9. Warning the owner to instruct children not to use the equipment in a manner other than intended,
10. Warning the owner to instruct children not to get equipment while it is in motion,
11. Warning the owner not to allow children to wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes and ponchos. These items can cause death by strangulation.
12. Warning the owner to instruct children not to climb when the equipment is wet.
13. Warning the owner to instruct children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard
14. Warning the owner to instruct children to remove their bike or other sports helmet before playing on the playground equipment.
15. Warning the owner to dress children with well-fitting and full foot enclosing footwear. Examples of inappropriate footwear are clogs, flip flops, and sandals.
16. Place the equipment on level ground, not less than 6 ft (1.8 m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires
17. Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury or death to the equipment user.
18. To prevent serious injury, cautionary statements shall be included which warn that children must not use the equipment until properly installed.
















ASSEMBLY INSTRUCTION



Part List &Hardware List (Box 1-MH10027)


A5  WoodBar-1pc	B7  Panel-1pc	C2  Panel-1pc
C3  Panel-1pc	D8  Panel-2pcs	D9  Panel-1pc
F4  Panel-1pc	F6  Panel-1pc	F7  WoodBar-1pc
F8  WoodBar-1pc	F9  WoodBar-1pc	G3  Panel-1pc
G4  Panel-1pc	G6  Slats-10pcs	

Part List (Box 2-MH10027)

A3  WoodBar-1pc	A4  WoodBar-1pc	A6  WoodBar-1pc
A7  WoodBar-1pc	A8  WoodBar-1pc	A9  WoodBar-2pcs
B6  WoodBar-1pc	B8  WoodBar-1pc	B9  WoodBar-2pcs
C1  WoodBar-3pcs	C4  WoodBar-1pc	C5  Side Rail-1pc
C6  WoodBar-1pc	C8  Panel-1pc	C9  Side Rail-1pc
E1  WoodBar-1pc	E2  WoodBar-1pc	E3  WoodBar-1pc
E4  WoodBar-1pc	E5  WoodBar-1pc	E6  WoodBar-1pc

Part List (Box 2-MH10027)

E7



WoodBar-1pc

G1




WoodBar-1pc

G2














WoodBar-1pc

G5












WoodBar-1pc















Part List (Box 3-MH10027)

A1 Panel-1pc 	B1 Panel-2pcs 	B2 Panel-2pcs 
B3 Panel-2pcs 	B4 Panel-1pc 	C7 Panel-1pc 
D5 Panel-1pc 	D6 Panel-1pc 	D7 Panel-2pcs 
G7 Panel-1pc 	E8 Panel-2pcs 	E9 Panel-1pc 
F1 Panel-3pcs 	F2 Panel-2pcs 	G6 Slats-4pcs 

Part List (Box 4-MH10027)

A2 WoodBar-1pc 	B5 WoodBar-1pc 	D1 WoodBar-3pcs 
D2 Panel-2pcs 	D3 Panel-1pc 	D4 Panel-1pc 
F3 Panel-1pc 	F5 Panel-1pc 	A6 WoodBar-1pc 
20 Power outlet-1pc 	21 LED lights-1pc 	

Hardware List (Box 1-MH10027)

1		2		3	
	Bolts Ø1/4" x60 mm - 40pcs		Bolts Ø1/4" x30 mm - 1pcs		Wood dowel Ø10 x 40 mm - 22pcs
4		5		6	
	Wood dowel Ø8 x 30 mm - 98pcs		Bracket-6pc		Wood Screws M4 x 15mm - 40pcs
7		8		9	
	Barrel Ø1/4" x 15 mm - 40pcs		Camlock-16pcs		Cam bolt-16pcs
10		11		12	
	Washer 15pcs		Steel Bracket -2pcs		Wood Screws M4 x 20mm-24pcs
13		14		15	
	Screws 1/4" x 30mm -24pcs		Bracket 42x15x15 -10psc		Wood Screws M3.5 x 12mm - 70pcs
16		17		18	
	Wood Screws M4 x 30mm - 38pc		Wood dowel Ø6 x 30 mm - 34pcs		Screws 1/4" x 50mm -11pcs
19		22		23	
	Bracket 42x15x15 -11Pcs		Bracket -2Pcs		Bracket-42x42 -1Pc


Hardware List (Box 1-MH10027)

24




M5 x 75mm -2pcs

25



M8x 80mm -2pcs

26




Bolts Ø1/4" x50 mm - 15pcs

27




Allen Key - 1pc
Clé Allen




Assembly Tools Required (Not Included)


Step 1:




Step 2:






Step 3:

4

2(pcs)





Step 4:


26	4
	
7(pcs)	16(pcs)
10	
	7(pcs)




Step 5:




Step 6:




Step 7:




Step 8:




Step 9:





Step 10:




Step 11:




Step 12:


1	3
	
10(pcs)	8(pcs)
	7
	
	10(pcs)




Step 13:




Step 14:




Step 15:




Step 16:




Step 17:



Step 18:




Step 19:




13




6(pcs)



Step 20:



17




2(pcs)

18




2(pcs)




Step 21:




Step 22:







Step 23:

1	7	13
		
6(pcs)	6(pcs)	4(pcs)
15	17	19
		
4(pcs)	8(pcs)	1(pcs)







Step 24:

1	7	13
		
6(pcs)	6(pcs)	4(pcs)
15	17	19
		
4(pcs)	8(pcs)	1(pcs)




Step 25:


1	7	13
		
2(pcs)	2(pcs)	4(pcs)
15	17	19
		
12(pcs)	4(pcs)	3(pcs)






Step 26:




Step 27:






13	16	17
		
4(pcs)	4(pcs)	6(pcs)




Step 28:



23	19	15
		
1(pc)	4(pcs)	20(pcs)




Step 29:




6	
28(pcs)	


Step 30:



Step 31:




25



2(pcs)

Note:"Drill a hole in the wall, then use a hammer to drive Plastic anchor number (25) into the wall."

Step 32:



12



4(pcs)

16



28(pcs)

22




2(pcs)


24




2(pcs)




Step 33:Finish

15		20	
6(pcs)		1(pc)	
14		21	
2(pcs)		1(pc)	



LED lights



Power outlet

