





Thank you for purchasing this desk. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.

Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Necessary Tools



Note: Some of the tools shown here are optional and are required only for quick assembly of this product
















Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.


This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.

This product takes approximately 45 MINUTES to assemble with 2 PEOPLE.


The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.







16 x2




17 x3




18 x2




19 x3




20 x1




21 x1




22 x1



23 x1




24 x2




25 x2




A x24 (3x15mm)



B x28 (6x40mm)




C x4 (6x30mm)



D x2 (6x65mm)



E x2 (6x12mm)



F x4 (5X40 mm)



G x12 (4X35 mm)




H x6 (4x20mm)



I x4 (Φ 16 mm)








J x4 (6X20 mm)








K x1

6x40MM bolt installation










1





A x12









9



E x2





10




J x4




11





B x4



12




13



G x4




14





Left

A x4





15 Repeat steps 11-15 for the second small drawer




H x2




16





B x4



17




18



G x4





19



Be careful not to overtighten the metal rods



20



A x4




21




H x2



22





Metal parts

A slightly damp cloth is the best cleaning agent for the metal parts.

Fixings

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Glass and acrylic furniture

Use glass cleaner or soapy water for cleaning, do not use anything abrasive as this may damage the surface of the product. Protect surfaces from scratches and marks by using mats and coasters.

Safety Instructions

Never drag furniture when moving it, always lift it.

Periodically check all fixings to ensure none have come loose and re-tighten where necessary.

Please take care when handling or moving the furniture as careless handling may cause damage or injury.

Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.

It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE