


Hall Tree

Assembly Instructions - Please keep for future reference



Dimensions

Width- 59.05inch

Depth-15.75inch

Height-78.74inch



WARNING



This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.

Important – Please read these instructions fully before starting assembly



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING
In order to help prevent overturning –
please follow these instructions













To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Components - Fittings

Please check you have all the panels listed below



Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

 (A) Cam Bolt x 117+2	 (B) 6*30mm Dowel x 107+2	 (C) Cam lock x 123+2	 (D) x 6set
 (E) 3*12mm Screw x 40+2	 (F) 4*30mm Screw x 40+2	 (G) 6*25mm Screw x4	 (H) Slide x8
 (I) 3*16mm Hook x 4set	 (J) 4*25mm Screw x 12+1	 (K) Straight Arm Hinge x 4set	 (L) 4*40mm Screw x 18+1
 (M) 6*20mm Dowel x 8+1	 (N) Drawer slide x 4	 (O) 3.5*14mm Back panel clip x 24set	 (P) 3.5*14mm Screw x 8+1
 (Q) 4*20mm round handle x 4set	 (R) 4*20mm Handle x 1set	 (S) Half-overlay Hinge x 4set	 (T) 4*8mm round handle x 4set
 (U) Anti-tipping Device x2	 (V) Perfect fit x 50	 (W) Allen key x 2	 (Y) Foot pad x18

Tools required Not Included



Phillips screwdriver
(medium & large)




Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.

1


DO NOT OVER TIGHTEN.
NE PAS SERRER EXCESSIVEMENT.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.

4












Assembly Instructions
























PART LIST

This product comes in 3 box.

 ⑧ x1 1530x365x12mm	 ⑪ x1 1513x33x15mm	 ⑬ x1 1513x33x15mm	 ⑮ x3 1001x61x15mm
 ⑮ x1 1913x365x15mm	 ⑯ x2 1913x33x15mm	 ⑰ x1 1913x365x15mm	 ⑳ x1 1398x348x3mm
 ㉑ x1 1876x350x15mm			



















PART LIST

This product comes in 3 box.

 ⑤ x2 1079x50x15mm	 ⑥ x4 300x50x15mm	 ⑩ x1 1513x265x15mm	 ⑫ x1 352*265*15mm	 ⑭ x1 1075x60x15mm
 ⑯ x4 1010x231x3mm	 ⑰ x1 1075x100x15mm	 ⑱ x1 1060x265x12mm	 ⑳ x1 340x264x15mm	 ㉓ x1 1024x33x15mm
 ㉔ x2 307x40x18mm	 ㉘ x1 315x261x15mm	 ㉟ x4 350x265x15mm	 ㉠ x4 212x146x12mm	 ㉡ x4 220x326x3mm
 ㉣ x2 300x100x12mm	 ㉤ x2 300x100x12mm	 ㉥ x1 1351x255x12mm	 ㉦ x2 288x255x12mm	 ㉧ x2 315x261x15mm
 ㉨ x1 315x261x15mm				


PART LIST

This product comes in 3 box.


				
① x1 385x380x15mm	② x1 385x380x15mm	③ x3 370x350x12mm	④ x1 1060x380x15mm	⑦ x1 1068x348x3mm
				
⑨ x1 1100x400x15mm	⑱ x1 1024x33x15mm	⑳ x1 1068x378x3mm	㉒ x1 1090x282x12mm	㉔ x4 285x40x18mm
				
③① x1 340x365x15mm	③② x1 340x365x12mm	③③ x1 502*348*3mm	③④ x1 374*382*12mm	③⑤ x1 305*33*15mm
				
③⑥ x2 359x50x15mm	③⑧ x4 330x146x12mm	③⑨ x4 330*146*12mm	Hardware kit x1	

Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3




Step 4




Assembly Instructions


Step 5



Step 6





Step 7





Assembly Instructions

Step 8





Step 9




Assembly Instructions


Step 10




step1





step2





step3



Step 11




Step 12






Assembly Instructions

Step 13

x8




Step 14




Assembly Instructions


Step 15



Step 16




Step 17




Assembly Instructions


Step 18



Step 19




Step 20




Assembly Instructions

Step 21





Step 22





Assembly Instructions



Step 23



Step 24





Step 25





Assembly Instructions

Step 26





Step 27





Assembly Instructions

Step 28




Step 29



Assembly Instructions

Step 30

Ziehen Sie die inneren und äußeren Schubladenführungen auseinander, bevor Sie sie an den Platten befestigen.
Tirez les glissières de tiroir intérieures et extérieures avant de les fixer au panneau.



Schieben Sie Schubladenführungen auseinander, bis das Schubladenschloss sichtbar ist, wie abgebildet.
Faites glisser les glissières du tiroir jusqu'à ce que vous puissiez voir la serrure du tiroir, comme illustré.



Äußerer Lauf
Roue externe

INNER RUNNER
Roue intérieure

Drücken und halten Sie die Schubladenläuferverriegelung gedrückt und fahren Sie dann fort, die Schubladenläufer auseinander zu schieben, wie gezeigt.

Appuyez et maintenez le verrou de la glissière du tiroir enfoncé, puis continuez à glisser la glissière du tiroir vers l'extérieur, comme illustré.



Äußerer Lauf
Roue externe


INNER RUNNER
Roue intérieure

INNER RUNNER
Roue intérieure

INNER RUNNER
Roue intérieure

N1



N2



Drawer slide x 4

Ihre inneren und äußeren Schubladenführungen sind bereit, an Platten befestigt zu werden.
Vos tiroirs intérieurs et extérieurs sont prêts à être fixés au panneau.

Step 31



3.5*14mm Screw x4

A



Cam Bolt x 4


N1



Drawer slide x2

Assembly Instructions

Step 32




(G) 6*25mm Screw x2

(B) 6*30mm Dowel x 3

(C) Cam lock x 5

Step 33





(J) 4*25mm Screw x4



(M) 6*20mm Dowel x 4

Assembly Instructions

Step 34




Step 35





Assembly Instructions

Step 36





Step 37





(C)	
Cam lock x 4	
(B)	
6*30mm Dowel x 4	
(A)	
Cam Bolt x 4	

Assembly Instructions


Step 38



Step 39




Step 40




Assembly Instructions

Step 41




Y




Foot pad x18

Step 42




A




Cam Bolt x 2

Assembly Instructions


Step 43





step1





step2



step3




Step 44




Assembly Instructions

Step 45



Assembly Instructions

Step 46





J





4*25mm Screw x4

Assembly Instructions

Step 47




Step 48




Assembly Instructions

Step 49


This is used to adjust the door panel in the up and down direction.





This is used to adjust the door panel in the left and right direction.





This is used to adjust the door panel in the front and rear.



If the door can't close, please adjust the hinges as below.




Step 50




Assembly Instructions

Step 51



Step 52




(F)



4*30mm Screw x 16





x4






31

Assembly Instructions



Step 53



Step 54





Step 55





Assembly Instructions



Step 56



Step 57





Step 58




Assembly Instructions

Step 59





Step 60



Assembly Instructions

Step 61



U



Assembly Instructions

Finish

