

INSTRUCTIONS

Packing List

1

Tent x 1

2

Small Triangle Connector x 4

3

Big Triangle Connector x 4

4

Flat Triangle Connector x 2

5

Flat Connector x 2

6

Connector x 20

A

Pole A x 1(11.5in)

E

Pole E x 3(13in)

B

Pole B x 10(13.8in)

C


Pole C x 15(15in)

D

Pole D x 8(15.8in)


Assembly

Step 1: E Pole x 1



Step 3:

C Pole x 5




D Pole x 4




B Pole x 4




Step 2: AB Pole x 1




Step 4:





Step 5:



Step 6:



Step 7:



Tips1: Please attention the hook-and-loop fastener is facing OUT when you assemble the bottom part. Then press the hook-and-loop fasteners on the bottom and the tent fabric together.

Tips2: Please confirm that the poles are pushed into the bottom of the connectors if you have problem in pressing the hook-and-loop fasteners together.

Tips3: We recommend two people to assemble the floor mat together.