



Installing Your Range Hood.

1. Measure the height of your ceiling from your floor to your ceiling.
2. Measure the height of your range.
3. Install your hood at a minimum height of 30" or a maximum height of 36" from the cooktop.
4. Measure the height of the range hood only (do not include the chimney pieces)
5. Do the math. Subtract height of range, distance between the cooktop and range hood, and hood height from ceiling height.

8 feet x 12 = 96 Inches (Ceiling Height)

- 36 Inches (Range Height)

60 Inches

- 30 Inches (Minimum Height Above the Range)

30 Inches

- 16 Inches (Height of Range Hood)

14 Inches (Total Space Left for Chimney)

Determine Which Size of Chimney Needed

Standard Chimney: Depending on model, your standard chimney will either be: Two 16" Chimney Sections or Two 19" Chimney Sections for 9ft-9.5ft ceilings.

Short Chimney: Two 12" Chimney Sections for 8ft. ceilings.

1 Piece Wall Chimney Extension: 1-36" and 1- 16" Chimney Section for 10ft. ceilings.

2 Piece Wall Chimney Extension: Two 36" Chimney Sections for 12ft. ceilings.

2 Piece Island Chimney Extension: Two 36" Chimney Sections for 10ft-12ft. ceilings.

Chimneys come in TWO Piece Sections and can be adjusted.