




ASSEMBLY INSTRUCTIONS






Assemble Precautions:

1. Each of the four pillars is unique and must be matched to the panel according to the letter indicators. Ensure the two types of wheels are correctly paired with the designated pillars. Carefully review the manual to confirm proper placement before assembly.
2. Two types of screws are included, each designed for specific holes. Refer to the manual to select the correct screw type for each step of the installation.




AA x26



AB x6




DE x1



DD x1

**Any accessories
missing or
product issues,
Please contact us.**



✉ E-mail:

Goosechef@163.com



1

AA x8

AB x2

DD x1

DE x1

Assemble Sequence

- 1 D → A
- 2 I/J/K/L → A
- 3 M/N → A

Cart Armrest


assemble stainless steel handle using (AB) long screws.

Locking Caster Wheels (2x)

assemble on the same side near the handle.

Universal Wheel (2x)

assemble on pillars (K) and (L)



2

AA x8

AB x4


DD x1

Main Support Frame:


Insert the egg rack into the frame, and assemble (AA) type screws from the bottom.

Bottom Shelf :

Use (AB) type long screws and fix the bottom bracket.



3





AA x10



DD x1

Hook Assemble:

Can be assemble on either side of the stainless steel handle based on your preference.



Bracket & Tray Assemble:

AA screws for securing the base of the tray and attaching the side columns.

Tips: The right side table features a foldable design. To secure the table when lifting, apply slight upward force to lock it in place. To fold it down, press the raised sections at the base simultaneously with both hands.

4

