

Power Recliner Chair

Assembly Manual

ME7A5102




CS.furniture@outlook.com

▲ CAUTION

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.
PLEASE READ AND KEEP FOR FUTURE REFERENCE.


COMPONENTS

BOX A Armrest L & R, Backrest, Wooden leg




- A** Backrest
1X
- B** Left Armrest
1X
- C** Right Armrest
1X
- D** Wooden Leg
4X

BOX B Seat Base




- E** Seat Base
1X
- F** Plastic Leg 1
2X
- G** Plastic Leg 2
2X
- H** Bolt
2X
- I** Hex Key
1X
- J** Adapter
1X
- K** Power Cord
1X


- 1 Attach the Wooden legs (D) to the bottom of the Armrest (B) & (C) by turning clockwise.




- 2 Locate the Adapter box and the Hardware pack with the red string at the bottom of Seat Base (E).




- 3 Attach the Plastic leg 1 (F) to the bottom of the Seat base (E) by turning clockwise. Attach the Plastic leg 2 (G) to the bottom of the Seat base (E) with Bolts (H) and Hex key (I).




- 4 Attach the Left Armrest (B) and Right Armrest (C) to the Seat Base (E). Align the metal plates and slide the armrests downward until fully locked.



- 5 Connect the Power Cable of the Left Armrest (B) to the Seat Base (E).



- 6 Slide the Backrest (A) into the metallic quick connectors of the base. Push down the back firmly until each side is locked into place and an audible "click" is heard.




7 Power connections.

7.1 Connect one end of Power Cord (K) into the Adapter (J).


7.2 Connect female head of the Adapter (J) into connection jack located at the bottom of the Seat Base (E).

7.3 Plug the other end of Power Cord (K) into the Power Outlet.

Note: After all the connections are made, the green LED of the Adapter will be lit up.



- 8 Assembly completed, it's ready to use.



Design Exquisite Furniture For Your Home

PRODUCT WARRANTY

- 1-year limited on cover against splitting, peeling, and/or tearing.
- 1-year limited on internal and external frame structure.
- 1-year limited on cushioning material, seat springs and mechanism.

Contact us:

We make all efforts to guarantee that the products you receive are in excellent condition. If there are any parts missing or damaged, the Customer Service Team will be happy to provide free replacements for you. We have professional warehouses where the current inventory of parts is enough so that they will arrive in your hands as fast as possible.

Assistance with assembly or product details is available; don't hesitate to get in touch with us to get priority service.

Our E-mail address: CS.furniture@outlook.com.



CS.furniture@outlook.com