


ASSEMBLY INSTRUCTION



PLEASE DO NOT RETURN TO STORE




**Please do not return this product to the retailer!
We are able to assist you in ANY way!**





**If you find that you have any trouble with assembly or
missing or damaged parts please contact the seller.**


Please carefully review the following precautions before proceeding with the installation:

1. The installation process for this product is complex, and it is highly recommended to have at least two individuals working together during the installation.
2. Prior to each step, please refer to the screw hole positions to ensure that the board is aligned correctly according to the images provided in the instruction manual. This will help prevent any errors.
3. In case power tools are used for installation, it is important to tighten the screws intermittently rather than applying excessive force continuously. This precaution will help avoid potential cracks around the screw holes.
4. If you encounter any difficulties or issues during the assembly process, please don't hesitate to reach out to us. We assure you that we will address your concerns and provide a solution within 24 hours.


Thank you for your attention to these important instructions.









25 x1




26 x2




27 x2




28 x1




29 x1




30 x2




31 x1




32 x3




33 x1




34 x1




35 x1



36 x1






Easy Installation:

-Can rotate the combination dial clockwise or counterclockwise


Set Your Own Password

-The password can be changed instantly
-No special tools required



1000 Combination Options

Change the password simply by pressing the button and setting the code in just a few seconds



Important Notes:

Password Setting

1. Password must be set when the lock is unlocked (default password is 0-0-0)
2. The reset position is located at the small hole on the lower edge of the outer ring; rotate the head until the internal button becomes visible
(Can be used with accessory O)
3. Insert a small cylindrical rod into the button, press it down, and rotate the combination dial to align your desired numbers in the center
4. Release the button to complete the password setting


Locking & Unlocking

Rotate to lock the device



After locking, randomly turn one or all combination dials to secure the lock

To unlock, rotate the dials to match the preset password

Hardware


A	x91 +3(spare)	B	x91 +3(spare)	C	x52 +4(spare)	D	x34 +3(spare)	E	x24 +1(spare)	F	x18 +1(spare)
											
Ø6x32mm				Ø6x30mm		Ø3.5x12mm		Ø4x25mm		Ø4x35mm	
G	x1	H	x1	I	x18	J	x1	K	x2	L	x3
											
N	x1	M	x2	O	x1	P	x1	Q	x6	R	x18
											
								M4x18mm			
S	x2	T	x16 +2(spare)	CL	x3	CR	x3	DL	x3	DR	x3
											
Ø5x352mm		Ø6x20mm		L350mm		L350mm		L350mm		L350mm	
CL	x1	CR	x1	DL	x1	DR	x1				
											
L300mm		L300mm		L300mm		L300mm					

STEP1





A	x8
	
Ø6x32mm	
B	x8
	

STEP2




STEP3

! DL=350mm
DR=350mm




DL	x2
	
L350mm	
DR	x2
	
L350mm	
D	x8
	
Ø3.5x12mm	


STEP4







STEP5



STEP6




DL=350mm
DR=350mm



DL	x1	F	x4
L350mm		Ø4x35mm	
DR	x1	D	x4
L350mm		Ø3.5x12mm	


STEP7



L	x1	Q	x2
		M4x18mm	


STEP8

A	x2
	
Ø6x32mm	
C	x2
	
Ø6x30mm	
B	x2
	
D	x4
	
Ø3.5x12mm	
DL	x1
	
L300mm	
DR	x1
	
L300mm	




STEP9



D	x4
	
Ø3.5x12mm	
CL	x1
	
L300mm	
CR	x1
	
L300mm	



STEP10




STEP11



A	x2
Ø6x32mm	
B	x2



STEP12



A	x5
	
Ø6x32mm	
T	x4
	
Ø6x20mm	

E	x6
	
Ø4x25mm	


STEP13



A	x2
	
Ø6x32mm	
B	x4
	


STEP14

B	x2
	
I	x5
	




STEP15

B	x5
	
C	x5
	
Ø6x30mm	
I	x3
	




STEP16




E	x4
	
Ø4x25mm	
I	x2
	
T	x4
	
Ø6x20mm	

STEP17




A	x10
	
Ø6x32mm	
B	x2
	
C	x2
	
Ø6x30mm	
M	x2
	
P	x1
	

STEP18




B	x8
	
C	x8
	
Ø6x30mm	

STEP19




A	x10
	
Ø6x32mm	
B	x2
	
C	x2
	
Ø6x30mm	

STEP20




E	x7
	
Ø4x25mm	
T	x4
	
Ø6x20mm	

STEP21




A	x4
	
Ø6x32mm	

STEP22




A	x14
	
Ø6x32mm	
B	x6
	
C	x4
	
Ø6x30mm	

STEP23




A	x2
	
Ø6x32mm	
B	x4
	


STEP24



B	x6
C	x6
Ø6x30mm	
I	x8




STEP25




E	x3
Ø4x25mm	
T	x2
Ø6x20mm	

STEP26




B	x8
C	x8
Ø6x30mm	

STEP27




B	x4
C	x2
Ø6x30mm	
E	x3
Ø4x25mm	
T	x2
Ø6x20mm	

STEP28




E	x1
	
Ø4x25mm	

STEP29





D	x2
	
Ø3.5x12mm	
J	x1
	
K	x2
	

STEP30





A	x18
	
Ø6x32mm	

STEP31





B	x2
	
C	x1
	
Ø6x30mm	

STEP32




B	x4

STEP33





B	x12
C	x6
Ø6x30mm	

STEP34



A	x6
	
Ø6x32mm	

STEP35




B	x6

C	x6
Ø6x30mm	


F	x6
Ø4x35mm	

STEP36



R	x18
0	

STEP37



Note: There are additional USB-A ports at the bottom of the power strip. You can plug the LED strip into the bottom of the outlet.

