

# User Manual

Arc Floor Lamp

## Introduction

Thank you for purchasing our arc floor lamp. Please read the following instructions carefully before use.

## Product Features

1. With a traditional foot switch, both children and adults can easily switch the lights.
2. The lampshade is composed of two parts. The paper rope lampshade is wrapped with a linen lampshade, which is quite design-oriented and combines modernism with country style.
3. Usage
  - On/Off: Step on the foot switch.
  - CCT: CCT can be changed by depressing the foot switch twice.

## Parameter

Lamp	
Power	MAX 60W
Material	Iron+Fabric+Paper
Socket Type	E26
Switch	Foot switch
Bulb	
Voltage	100-120V
Power	12W
Brightness	1200LM
CCT	3000K-6500K
Life	30000h



## Cautions

1. Please make sure that the voltage is 100-120V, which is standard for US. This product can only be used between 100-120V.
2. Unplug before cleaning.

## Warranty and Our mission

Light the world, Warm your heart, which is the goal that we have been pursuing. We'd like to provide the best lamps and service to you. We provide a 12-month warranty for you. If you have any questions or suggestions, please contact us soon, we would do our best to solve the problem and improve ourselves. Wish you enjoy the lamp and our service.

## Package List



## Assembling

- ① Connect the straight tube and the lamp holder tube.
- ②-⑤ Connect the straight tube to another straight tube.
- ⑥-⑦ Tighten the screws with a wrench to connect the base and the straight tube.
- ⑧ Put the velcro at both ends of the cloth lampshade together.
- ⑨-⑩ Clip the bracket to the cloth lampshade.
- ⑪-⑬ Install the two lampshades to the lamp holder, lock the lampshade on the lamp holder with the lamp nut;
- ⑭ Install the bulb to finish the assembling.