










9018


Accessories list 2/2

NO	DESCRIPTION	DRAWING	QTY	NO	DESCRIPTION	DRAWING	QTY
A	Backrest		1	H	Flat Washer		8
B	Sofabase		1	I	Screw		8
C	Seatcushion		2	J	Wrench		1
D	Cushion		2				
E	Pilow		2				
F	Front Leg		2				
G	Back Leg		2				


Accessories list 1/2

K	Left Armrest		1	L	Right Armrest		1
---	--------------	---	---	---	---------------	---	---


STEP:1



STEP:2




STEP:3




STEP:4

Please note that after unpacking, gently tap the item and allow it to rest undisturbed for 72 hours to fully restore its original shape.



STEP:5



Complete

