

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

SOFA TABLE

723447

ITEM : 723447




ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!
1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
2.This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION


Z-HARDWARE

A	TOP		1PC	1	SILICONE GASKET		4PC
B	BASE		1PC				



ITEM : 723447
ASSEMBLY INSTRUCTIONS
STEP 1





STEP 2



STEP 3





COASTERFURNITURE.COM

Note: Dimension tolerance $\pm 5\%$