











ASSEMBLY INSTRUCTIONS

Ax1	 Seat
Bx2	 Front leg
Cx2	 Rear leg
Dx4	 Adjuster cap
Ex4	 M8*60mm Screw
Fx4	 M8*50mm Screw
Gx8	 M8 Spring washer
Hx8	 M8*22mm Flat washer
Ix1	 M8 Allen key




WARNING:

DO NOT STAND ON THE PRODUCT, DO NOT USE THIS PRODUCT AS A STEP LADDER.

DO NOT USE THIS PRODUCT UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED.


PLEASE DO NOT USE KNIFE TO OPEN ANY PARTS OF THE BOX OR PRODUCT.

②




Tighten all the screws to 80% of maximum tightness

③



Close the zipper of bottom Non-Woven fabric.
Tighten all the screws to
100% of maximum tightness

④



There are 4 small
adjusters on the
legs ,ensure these are
adjusted so the chair sits
level