


INSTRUCTION MANUAL




STORAGE CABINET

ASSEMBLY INSTRUCTIONS





















- Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.
- Identify each component and refer to the provided assembly diagram or step-by-step instructions.
- Assemble the furniture in the order specified to ensure proper alignment and fit.
- Use the provided tools or recommended tools for assembly. Do not use excessive force when tightening screws or bolts.
- If any difficulties arise during assembly, consult the troubleshooting section or contact our customer support.



TOOLS REQUIRED




HARDWARE

| | | | |
|--|--|---|--|
| A M6x35mm Bolt  30PCS | B M15x10mm Eccentric Wheel  30PCS | C M8x30mm Wooden Dowel  22PCS | D M3x12mm Screw  18PCS |
| E receptacle  1PCS | F M4x16mm Screw  2PCS | G Handle  2PCS | H Back Panel Latch  4PCS |
| I M3x16mm Screw  4PCS | J Washer  4PCS | K Plastic Expansion  2PCS | L Anti-tipping Strap  2PCS |
| M M4x14mm Screw  2PCS | N M4x35mm Screw  2PCS | O 300mm Cabinet Slider  4PCS | P 300mm Drawer Slider  4PCS |
| Q M4x30mm Screw  8PCS | R Screw Hole Cover  14PCS | | |


PART




STEP 1




Secure bolt A to panels 4, 5, 6, and 7





STEP 2




Connect panels 4 and 5 to panel 2 using wooden dowel C, then tighten eccentric wheel B clockwise





STEP 3




Connect panels 6 and 7 to panel 3 using wooden dowel C, then tighten eccentric wheel B clockwise







STEP 4




Installing screw A, then use screw D to secure slide rail O to panel 2






STEP 5




Installing screw A, then use screw D to secure slide rail O to panel 3





STEP 6




Connect panels 8 to panel 3 using wooden dowel C, then tighten eccentric wheel B clockwise





STEP 7




Connect panels 9 and 10 to panels 3, 6, 7, using wooden dowel C, then tighten eccentric wheel B clockwise



STEP 8




Connect panel 2 to the assembled component using wooden dowel C, then tighten eccentric wheel B clockwise




STEP 9


Slide and insert back panel 11 into the assembled component




STEP 10




Secure bolt A onto panel 1




STEP 11




Connect panel 1 to panels 2 and 3, using wooden dowel C, then tighten eccentric wheel B clockwise, and finally, apply hole sticker R




STEP 12




Secure back panel fastener H to the back panel using screw I, then install the anti-tip device on panels 4 and 6




STEP 13




Secure bolt A onto panel 12






STEP 14




Secure slide rail P onto panels 13 and 14 using screw D



STEP 15




Connect panels 13 and 14 to panel 12 using wooden dowel C, then tighten eccentric wheel B clockwise, and finally, apply hole sticker R





STEP 16


Slide and insert drawer bottom panel 15 into the assembled component






STEP 17




Attach panel 16 to the assembled component and secure it with screw Q




STEP 18



Secure handle G to panel 12 using screw F






STEP 19




Place the drawer inside the cabinet.







STEP 20



Place USB socket E into the groove on panel 1 and secure it with screw D



STEP 21



Use components K, J, and N to assemble hardware L on the wall to prevent tipping.

MAINTENANCE AND CARE



Following these few basic steps will help to ensure that you enjoy your furniture for a long time:

Do not expose your furniture to direct sunlight, dampness or any heat, like a hot cup of coffee or tea. Always use a coaster.

Dust with a clean, damp, lint free cloth.

Use a damp cloth with water or mild detergent to clean all surfaces - do not use chemicals or paint thinner which will fade the surface.

Place a piece of felt or a pad under the legs of your furniture to avoid scratching the floor.

WARRANTY INFORMATION



Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.