

APEX Series

USER GUIDE & ASSEMBLY INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using the product, basic safety precautions should always be followed to reduce the risk of injury including the following:

- This product must be assembled by an adult.
- Keep children and pets away while assembling the product.
- Do not let children climb on or play with the product.
- Always use the product on a firm, level ground.
- Do not use this product if any parts are missing, damaged, or worn.
- To avoid scratching the floor, assemble the product on a soft surface, such as a carpet.
- Do not over-tighten the fasteners.
- Regularly examine the product for wear and tear. Stop using the product at the first sign of damage or if parts become detached.
- Do not use power tools to assemble the product. Power tools may strip or damage the parts.
- Do not stand on the seat.
- Do not sit on the armrest.
- Keep all sharp objects away from the upholstery.
- Do not hang anything on the product.

1. Assembly

- For additional illustrated assembly steps, refer to the end of the written instructions.

2. Before First Use

- Suffocation Hazard: Packaging materials and small components such as screws, bolts, and other fasteners can pose a suffocation hazard. Always keep these parts out of reach of children and pets during assembly and ensure they are securely fastened to the product to prevent them from becoming loose over time.

- Children's Safety: Never leave children unattended with the chair. Teach children not to play with the chair, as it is not a toy. Climbing on the chair or playing with its moving parts can lead to falls or injuries. Additionally, ensure the chair is adjusted to a safe and appropriate height for children's use to prevent their feet from dangling, which can cause discomfort or pressure.

- Pet Safety: Be mindful of pets around your chair products. Pets, particularly those with a tendency to chew or claw, can damage the chair or even ingest small parts, leading to potential injury or health issues. Consider using protective covers or deterrents if your pets are known to chew on furniture


- Remove all the packing materials.

- Review all components before assembly. Check the product for transport damages.


SAFETY INFORMATION



This product is designed for **one person** to sit at a time.



DO NOT use the chair unless all bolts, screws and knobs are tight.



DO NOT use the chair if any of the components is missing or damaged.




DO NOT stand on the chair as a step stool or a ladder.




DO NOT tilt the chair forward, left, or right while sitting.



Be careful **NOT TO FALL** off from the chair.



Be careful, as some parts may be **sharp** and **heavy**.



Regularly check and thighten all bolts, screws, and knobs.



Failure to follow these warnings may cause **serious injuries.**



Be careful **not to hit** the furniture edges.




Keep in a **dry and cool** place.





When **moving** the object, proceed with **caution.**

IT'S TIME TO UPGRADE YOUR CHAIR!


CHAIR PARTS



BACK x 1



CENTRAL BASE x 1



BASE x 5


GAS LIFT x 1


WHEEL x 5


SEAT x 1


ARMREST x 2


CONTROL MECHANISM x 1

HARDWARE


ARMREST BOLT M6*25 X8


TILTING BOLT M6*20 X4


BASE BOLT M6*14 X 10



BOLT CAP X8


ALLEN KEY


We recommend keeping your **Allen key** for future maintenance.

STEP 1. BASE





Take out the base cover first

1




2

BASE BOLT X10




3




Ouch! Be careful not to get your hands caught in the gap.


4



5




STEP 2. **BODY**




1


TILTING BOLT X4




2




TILTING ASSEMBLY SEQUENCE




IMPORTANT NOTICE



1 THE BOLT HOLES SHOULD BE ALIGNED



2 UNDER-TIGHTEN THE BOLTS




3 TIGHTEN ALL BOLTS


LOOSE BOLT ALERT!


When the bolts seem loose, detach the armrests and try inserting the bolts directly into their holes.


*Using an electric drill can damage the chair. Please re-tighten bolts manually.




























Finally tighten all the bolts

OPTIONAL




USER GUIDE

CHECK!!




If the **CONTROL MECHANISM** is properly installed, it should be on your **RIGHT.**


HEIGHT ADJUSTMENT




ADJUSTABLE FLIP-UP ARMRESTS



TILTING TENSION CONTROL



TILTING LOCK



CARE & MAINTENANCE

Proper care and regular maintenance will help keep your chair clean and in good working condition.



CLEANING

- Clean regularly with a soft, dry or slightly damp cloth.
- Wipe up spills promptly with a clean cloth.
- Do not use abrasive cleaners, harsh chemicals, or excessive moisture.
- Follow any care instructions specific to the materials used on your chair.

REGULAR MAINTENANCE

- Periodically check and tighten all screws, bolts, and connections.
- Make sure the casters, base, and other components remain securely attached.
- Check regularly for signs of wear, looseness, or damage.
- Do not use the chair if any component is damaged or unstable.

CARE TIPS

- Use the chair on a stable, level surface.
- Avoid prolonged exposure to excessive heat, direct sunlight, or moisture.
- Do not drag the chair roughly across the floor.
- Use the chair only as intended and within the recommended weight capacity.