


Painted Wooden Bed 90 cm

Assembly Instructions



IMPORTANT! PLEASE KEEP FOR FUTURE REFERENCE

IMPORTANT INFORMATION

WARNING: This bed is not suitable for children under 4 years

WARNING: Do not place this child's bed near heat sources, windows and other furniture.

WARNING: Do not use this child's bed if any part is broken, torn or missing.

It is recommended that you always follow the manufacturer's instructions to assembly this product.

This product is intended for use by children over 4 years of age.

Children are likely to play, bounce, jump and climb on beds, therefore the child's bed should not be placed too close to other furniture or windows, blind cords, curtain pulls or other strings or cords and should be placed either tight to the wall or have a gap of 300mm between the wall and side of bed.

Please do not dismantle this bed once built.

Recommended Mattress Size: 90cm x 190cm (UK Single) with a depth of no more than 23cm.

It is necessary to frequently ventilate the room in order to keep the humidity low and to prevent mould in and around the bed.

.yrassecen nehwnethgit-er dna meti eht fo sgnixfi eht lla kcehc yllacidoirep esaelp

Safety Advice

Please take the time to carefully read through the whole of these instructions before you commence.

Keep these instructions for future reference.

Unpack, inspect and check off all of the contents.

Please dispose of all packaging safely.

Small component parts could choke a child if swallowed.

We strongly recommend that you keep children well away from the work area.








It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid scratching this product and to protect your floor.

This product is heavy. Take extreme care when lifting to avoid personal injury or damage to the product.

Assemble the product as close to its intended final position in the room as possible.

We Strongly urge that you do not use Power Tools, such as drills or electric screwdrivers during this assembly as this could cause irreparable damage to your product and will invalidate the warranty

HANDY HINT: If you keep the hardware in a bowl during assembly you will be less likely to lose them.




CUSTOMER SERVICE

HARDWARE



A

1/4 x 100 Bolt x4



B

4.0 x 35 Screw x30




C

Wooden dowel x8
10 x 40mm




D

Nut 1/4 x4




E

Allen key x1



F


63mm Spacer x1




G

Caps Ø17 x4


PARTS




1




2




- 3** Attach the centre slat first by pushing the side rails together so that the slat is flush against the side rail, before inserting the screws.



- 4** Next attach the remaining slats.
Place the slats onto the side rail supports and
distribute evenly by using the spacer provided.





5



Do Not Use Power Tools

6



4x

General Care

Wipe clean with a slightly damp soft cloth. Avoid the use of all household cleaners and abrasives. When moving your furniture, carefully lift into place. Never drag or push the pieces across the floor as this will cause damage to the joints and could result in failure to the product that will invalidate the warranty.

Recommendations

Periodical re-tightening of fixings.

Warning

This unit is heavy. Please use an assistant when lifting.