












ASSEMBLY INSTRUCTION


SOFA TABLE

A Left Leg  1PC	B Right Leg  1PC	C Cross Bar  3PCS	D Cross Bar  1PC
E Frame  2PCS	F Upper Glass  1PC	G Lower Glass  1PC	H Bolt 1/4"*10mm  20PCS
I Glass Holder Ø16*10mm  12PCS	J L-Allen Key 4mm  1PC		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


- 1** Put the left & right leg (A & B) on the smooth and stable working stand. Insert the cross bars (C & D) to the left & right leg (A & B), using bolt (H) and L-allen key (J) to tighten.




- 2** Attach the glass holders (I) to the cross bars (C & D).



-
- 3** Attach the frames (E) to the left & right leg (A & B) and cross bar (D). Using bolts (H) and L-allen key (J) to tighten.



-
- 4** Attach the upper glass (F) and lower glass (G) onto the cross bars (C & D).



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.