



ASSEMBLY INSTRUCTION


SKU:N725P186645



PARTS LIST




①




X 1

②




X 1

③




X 1

④




X 1

⑤




X 1

⑥




X 1

⑦



X 1

⑧




X 3

⑨




X 2

⑩




X 1

⑪




X 1

⑫




X 1

14




X 1

15




X 2

16




X 1

17




X 1

18




X 1

19




X 2

20




X 2

21




X 2

22




X 2

23

















X 1

24




X 1


Hardware:

 32 x A	 32 x B	 31 x C	(CL)  2 x D
(CR)  2 x D	(DL)  2 x D	(DR)  2 x D	 16 x E Ø3.5*12
 4 x F Ø4*35	 8 x G	 1 x H	 4 x I
 4 x J Ø3*14	 4 x K	 8 x L Ø4*30	 4 x M
 8 x N M4x16	 4 x O	 24 x P Ø4*14	 2 x Q
 2 x R	 2 x T Ø4*14	 42 x U	 6 x V


STEP 1




STEP 2




STEP 3



STEP 4




STEP 5




B x 7


C x 6

STEP 6






B x 7



C x 6


V x 2


STEP 7




STEP 8




STEP 9




STEP 10





STEP 11





STEP 12




STEP 13




STEP 14








STEP 15



STEP 16








STEP 17



STEP 18



X 2



STEP 19



P x 16






Attention: For safety and stability, we suggest you have to secure the anti-tip accessories to the wall to prevent tipping, injury, and property damage.

Installation Completed

Cabinet Door Adjustment Instructions




Height adjustment:

- Locate the height adjustment screws on the hinge.
- Use the Phillips screwdriver to either tighten or loosen the screws to raise or lower the cabinet door as desired.



Side-to-side adjustment:

- If the cabinet door needs to be moved closer to or away from the cabinet frame, locate the side-to-side adjustment screws on the hinge.
- Use the Phillips screwdriver to adjust these screws and gradually move the door in the desired direction.



Depth adjustment (if applicable):

- Check if the cabinet door needs to be brought closer to or further away from the cabinet frame.
- For-depth adjustment, locate the depth adjustment screws on the hinge.
- Use the Phillips screwdriver to turn these screws clockwise or counterclockwise accordingly.

