

WING CHAIR W/OTTOMAN

ASSEMBLY INSTRUCTION



Assembly Instruction


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.














Warning !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME PER UNIT: 20 MINUTES

PARTS IDENTIFICATION			z	HARDWARE PACKAGE		
A	SEAT CUSHION	 1PC	1	LOCK WASHER Ø1/2"		8PCS
B	FRONT LEGS	 2PCS	2	FLAT WASHER Ø7/8"		8PCS
CL	LEFT BACK LEG	 1PC	3	BOLT Ø5/16"x1-1/4"		8PCS
CR	RIGHT BACK LEG	 1PC	4	ALLEN WRENCH Ø5/16"		1PC
D	OTTOMAN CUSHION	 1PC	5	SCREW Ø8x1-3/4"		16PCS
E	OTTOMAN LEG	 4PCS				

STEP:1



STEP:2



STEP:3

