

Using Instruction of Electronic (EMH) Safe

First opening: For the first opening, please take off the cover (on the middle of keypad), then take out the emergency key from the accessories box, insert the key into the lock hole, turn the key, then turn the handle to open the door. After that, put 4 batteries of 1.5V in the battery box (on the back of the door), then leave the door open and take the keys out.

● Change the personal code

Press the red or green reset button(on the back of door), the yellow light will be on, then input any 3-8 digits you want, press “#” to confirm, yellow indicator light off followed by one beep, indicating that the new code have been accepted and stored.

Press reset button

input any 3-8 digits

press “#”

● Change the master code

Press “00”, press the red or green reset button(on the back of door), the yellow light will be on, then input any 3-8 digits you want, press “#” to confirm, yellow indicator light off followed by one beep, indicating that the new code have been accepted and stored.

Press 0, 0

Press reset button

input any 3-8 digits

press “#”

● Open the safe

Input the code, followed by one beep and yellow light flashing, then press “#” to confirm, the green light will be on, rotate the handle in 5S and pull out, the door is opened.

If the code you input is incorrect, there will be 5 beeps sound.

● Mute function

1. Long press the number 1 button for about 3 seconds to turn off the sound.
2. Again, long press the number 1 button for about 3 seconds to turn on the sound.

● Notice

1. put 4 batteries of 1.5V in the battery box. you will hear a "beep" confirmation sound of power on, indicating that the circuit is connected and working
2. After pressing any key without any subsequent key input for about 8 seconds, it enters a sleep state.
3. The functions of * and # are the same. Indicates confirmation.
4. If the code you input is incorrect, there will be 5 beeps sound. If 3 incorrect codes input continuously, the keypad will be blocked with beeps sound for 20s. If another 3 incorrect codes input again, then the keypad will be blocked 5min.
5. If both the red light and green light are on, indicating that you should change the batteries. Please have a test before you close the door.
6. If you forgot the code, use the emergency key to open the safe as the first opening, and then press the red or green button(on the back of door) to reset the code.
7. Factory personal code: 159. (Master code is empty)

Please keep the emergency keys out of the safe.