

# LP1044

## Rechargeable Pen Light



OR



Not Included



### Features

Constructed with aircraft-grade aluminum

LPE optics

Push/pull focus beam

Textured grip

High quality pocket clip

Tactical on/off button

IPX4 waterproof rating




Dual powered (USB or 2 AAA)

### Product Warranty

The LP1044 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase.

For warranty claims please contact us by calling 801-553-8886 or sending an email to [info@simpleproducts.com](mailto:info@simpleproducts.com)

#### ANSI/PLATO FL1 STANDARD

			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
<b>10850 3.7V 750mAh Rechargeable Battery</b>			
High	360 lm	1h 30m	70m
Low	50 lm	7h	22m
<b>2 AAA Batteries</b>			
High	100 lm	4h	35m
Low	12 lm	12h	12m

### Operation Instructions

**On/Off:** Press and release the button on the tail cap to turn the light on and off.



**Cycle Modes:** First turn the light on by pressing down the button on the tail cap completely and releasing. Half-press the button to cycle through modes (High/Low).

Light automatically resets to High mode when turned off.

**Focus Head:** To focus the light beam, gently push the head away from the light to extend it. Pull the head back towards the light to widen the beam.



### Charging Instructions

The charging port can be found beneath the sliding cover near the head of the penlight. Slide the cover towards the tail cap to reveal the charging port.



Using the USB-C charging cable included with the light, plug the small end of the charging cable into the port on the penlight. The larger end of the charging cable can be plugged into a USB wall adaptor.



The indicator light next to the charging port will turn red to indicate that it is charging. Once fully charged, the same light will turn blue. This light will not turn on while it is charging.

Replacement USB-C cables can be purchased at most big box retailers. We recommend using one that is 5 volts.

The LP1044 has a charge time of approximately 3 hours.

### Battery Replacement

The LP1044 can also be used with 2 AAA alkaline batteries.

To use with 2 AAA batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide out the rechargeable battery. Store the rechargeable battery in a cool, dry, and protected place.

Insert both AAA batteries into light (+) side first. Re-attach the tail cap by pressing down lightly and turning it clockwise until tight.



If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.