ASSEMBLY INSTRUCTIONS



Instructions:

1.Insert the Harp (D) into the Saddle (F).

2.Put the Washer (B) onto the Harp (D).

3.Put the Shade (C) onto the Washer (B).

4.Put the Washer on the shade (B) tighten with Finial (A)

5.Please Screw (1)1-Way 60Watt Bulb into Socket (E).

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER)AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY.IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET,REVERSE THE PLUG.IF IT STILL DOES NOT FIT,CONTACT A QUALIFIED ELECTRICIAN.NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.DO NOT ALTER THE PLUG.