




INSTALLATION

Product Manual




IMPORTANT INFORMATION!

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





AVOID SCRATCHES!

In order to avoid scratching this furniture should be assembled on a soft layer—could be a rug.



IMPROVE EFFICIENCY !

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



ANTI-TOPPLE WARNING !


Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.

IMPORTANT !




It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.

Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.




Please prepare the following tools



When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 41



M5 x 42 mm

B x 41




Ø 15 x 12 mm

C x 53



M5 x 40 mm

D x 38



Ø 8 x 40 mm

E x 152



M3.5 x 14 mm

F x 10



M6 x 12 mm

G x 8



M6 x 25 mm

H x 2



M3 x 25 mm

I x 8



M3 x 14 mm

J x 18



K x 12



Ø 6 mm

L x 8




M4 x 16 mm

M x 4



6612-96

N x 2



M5 x 55 mm
Ø 8 x 60 mm


O x 2




P x 8



Q x 4



R x 4



S x 20




Ø 21 x 1 mm


x 1




#4

④2 x 1








⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


*This is a permanent label.
Do not remove!*




ASSEMBLED BY 2 ADULTS

1




C x 2
M5 x 40 mm




Secure plate 10 to plate 8 using screws (C).





2




Connect plate 8 and 10 to plate 9 using wooden dowels (D), and secure them with screws (C).




3

A x 2  M5 x 42 mm	E x 10  M3.5 x 14 mm	P x 2 	
--	---	--	---



First screw eccentric rods (A) to plate 17, then secure hinges (P) to plate 17 using screws (E) .



4

B x 2





Ø 15 x 12 mm


D x 2



Ø 8 x 40 mm





Connect plate 17 to plate 9 using wooden dowels (D), then insert the eccentric wheel (B) and tighten it by turning clockwise.





5

E x 14
M3.5 x 14 mm

P x 2



First secure part 40 to plate 16 using screws (E), then secure hinge (P) to plate 16 using screws (E).




6



E x 4




M3.5 x 14 mm




Secure hinges (P) in plate 49 to plate 9 using screws (E).



7

E x 14  M3.5 x 14 mm	P x 2 	
---	--	---







Secure hinges (P) and part 41 to plate 13 using screws (E).

8

E x 4



M3.5 x 14 mm






Secure part 41 in plate 13 to plate 8 using screw (E).

9

A x 2
M5 x 42 mm

E x 10
M3.5 x 14 mm

P x 2



First screw eccentric rods (A) to plate 20, then secure hinges (P) to plate 20 using screws (E).

10

B x 2





Ø 15 x 12 mm


D x 2





Ø 8 x 40 mm




Connect plate 20 to plate 11 using wooden dowels (D), then insert the eccentric wheel (B) and tighten it by turning clockwise.



11





Connect plate 7 to plate 8, 9, and 11 using wooden dowels (D).



12


C x 10
M5 x 40 mm






Secure plate 7 to plates 8, 9, and 11 using screws (C).

13

A x 9



M5 x 42 mm






Screw eccentric rods (A) to plate 7.

14

B x 2



Ø 15 x 12 mm






Connect plate 5 to plate 7, then insert the eccentric wheel (B) and tighten it by turning clockwise.

15

B x 5



Ø 15 x 12 mm



Connect plate 4 and 6 to plate 7, then insert the eccentric wheel (B) and tighten it by turning clockwise.

16

B x 2








Ø 15 x 12 mm

C x 4



M5 x 40 mm



Connect plate 3 to plate 7, then insert the eccentric wheel (B) and tighten it by turning clockwise.
Secure plate 4 and 6 to plate 5 using screws (C).

17

G x 8





M6 x 25 mm

x 1




#4







Secure plate 1 to plate 3 using screws (G).
Secure plate 2 to plate 4 using screws (G).

18

D x 4



Ø8 x 40 mm




Install the wooden dowels (D) into plate 13, 16, 17, and 20.
Insert plate 22 along the available slots.

19


C x 6



M5 x 40 mm






Secure plate 10 to plate 24 using screws (C).




20



A x 4
M5 x 42 mm



Screw eccentric rods (A) to plate 27 and 31.

21

C x 10  M5 x 40 mm	D x 2  Ø 8 x 40 mm	
---	---	---



Connect plate 27 to plate 10 and 24 using dowel (D), and secure them with screws (C).

22

B x 2





Ø 15 x 12 mm



D x 2



Ø 8 x 40 mm



Connect plate 27 to plate 32 using wooden dowels (D), then insert the eccentric wheel (B) and tighten it by turning clockwise.



23

B x 2




Ø 15 x 12 mm



D x 2



Ø 8 x 40 mm




Connect plate 32 to plate 31 using wooden dowels (D), then insert the eccentric wheel (B) and tighten it by turning clockwise.






24

D x 4




Ø8 x 40 mm






Install wooden dowels (D) into plate 27 and 31.

25

A x 14



M5 x 42 mm






Screw eccentric rods (A) to plate 26, 28, and 30.

26

B x 4



Ø 15 x 12 mm





Connect plate 28 and 30 to plate 29, then insert the eccentric wheel (B) and tighten it by turning clockwise.

27


B x 8



Ø 15 x 12 mm



Connect plate 28 and 30 to plate 27 and 31, then insert the eccentric wheel (B) and tighten it by turning clockwise.




28


E x 8



M3.5 x 14 mm




Secure part 40 to plate 26 using screws (E).



29

A x 2





M5 x 42 mm



E x 6



M3.5 x 14 mm



First secure part 41 to plate 23 using screws (E), then screw eccentric rods (A) to plate 23.







30


B x 4



Ø 15 x 12 mm



Connect plate 23 and 26 to plate 25, then insert the eccentric wheel (B) and tighten it by turning clockwise.




31


E x 14




M3.5 x 14 mm



Secure plate 23 and 26 to plate 24 and 27 using screws (E).





32





Insert plate 33 into the available slots.

33




Connect plate 12 to plate 23, 24, 27, 31, and 33 using dowels (D), and secure them with screws (C).






34


Insert plate 33 into the available slots.



35



Screw eccentric rods (A) to plate 34.



36

C x 10








M5 x 40 mm

D x 6



Ø8 x 40 mm






Connect plate 34 to plate 24, 25, 27, 29, and 31 using dowels (D), and secure them with screws (C).

37

B x 2



Ø 15 x 12 mm



Connect plate 35 to plate 34, then insert the eccentric wheel (B) and tighten it by turning clockwise.

38

F x 10




M6 x 12 mm

x 1




#4



Install part 38 to plate 34 using screws (F).

Note: Do not fully tighten.






39

E x 6



M3.5 x 14 mm




Secure part 38 to plate 37 using screws (E).

40


E x 4



M3.5 x 14 mm



Secure part 38 to plate 36 using screws (E).




41




E x 4



M3.5 x 14 mm



Secure part 39 to plate 36 and 37 using screws (E).




42

E x 4





M3.5 x 14 mm



O x 2




Secure brackets (O) to plate 34 using screws (E).




43

A x 6  M5 x 42 mm	I x 8  M3 x 16 mm	Q x 4 	
--	--	--	---



Screw eccentric rods (A) to plate 12.
Secure magnets (Q) to plate 12 using screws (I).





44



B x 6



Ø 15 x 12 mm



Connect the assembly unit to plate 12, then insert the eccentric wheel (B) and tighten it by turning clockwise.







45

E x 18



M3.5 x 14 mm

J x 18



First insert clips (J) into the slots on the back panels and secure them with screws (E).




46

K x 12



Ø6 mm

Install pins (K) to plate 3,
11, 27, and 31.





47





S x 20



Ø21 x 1 mm



Place plate 21 onto the pins (K).



48

E x 2



M3.5 x 14 mm

L x 2






M4 x 16 mm

M x 1



6612-96

R x 1




Secure part (R) to plate 18 using screws (E).
Secure handle (M) to plate 18 using screws (L).

49



E x 6




M3.5 x 14 mm




Secure plate 18 to hinges (P) on plate 17 using screws (E).



50

E x 2  M3.5 x 14 mm	L x 2  M4 x 16 mm	M x 1  6612-96	R x 1 	
--	--	---	---	---





Secure part (R) to plate 19 using screws (E).
Secure handle (M) to plate 19 using screws (L).

51


E x 6



M3.5 x 14 mm



Secure plate 19 to hinges (P) on plate 20 using screws (E).



52

E x 2



M3.5 x 14 mm

L x 2






M4 x 16 mm

M x 1



6612-96

R x 1




Secure part (R) to plate 14 using screws (E).
Secure handle (M) to plate 14 using screws (L).

53



E x 6





M3.5 x 14 mm




Secure plate 14 to hinges (P) on plate 13 using screws (E).



54

E x 2  M3.5 x 14 mm	L x 2  M4 x 16 mm	M x 1  6612-96	R x 1 	
--	--	---	---	---






Secure part (R) to plate 15 using screws (E).
Secure handle (M) to plate 15 using screws (L).

55


E x 6



M3.5 x 14 mm







Secure plate 15 to hinges (P) on plate 16 using screws (E).




56


N x 2
M5 x 55 mm
Ø8 x 60 mm




1.




2.



3.





4.





Install the anti-tip device as shown in the diagram.


57




Install the light strip as shown in the diagram.




Step 1



Step 2



Step 3



Step 4

WARRANTY

WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

RETURNS

CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.