



## 8-Tier Cookware Stand (Unassembled) CWS8KD



If you need assistance, please call 1-877-ENCLUME  
**Enclume Design Products**  
24 Colwell Street, Port Hadlock, WA 98339

Enclosed you will find everything needed for the assembly and use of your cookware stand. **Two people are highly recommended for assembly** and make this process much easier and less frustrating. The parts and hardware included are:

### Hardware included:

- 24 – Barrel Bolts – #10 x 24 x 7/16"
- 24 – Barrel Screws – #10 x 24 x 5/16"
- 3 – Felt Pads
- 2 – 5/32" Hex Key Wrenches

### Components included:

- 3 – Uprights
- 8 – Sets of Shelves #1 - #8 (each set contains 3 shelves)

## ASSEMBLY INSTRUCTIONS

- 1) Unpack the rack box, layout the contents, and match them to the hardware and component lists above.
- 2) Place two of the three **uprights** on a firm surface with what will be the lower ends of the **uprights** (each finished with a right-angle bend) extending to your right.
- 3) Locate a **shelf set** (set of three) and begin to place the shelves in the "lowest shelf set" space (see above diagram). Using two of the three shelf pieces, attach the two shelf pieces to the lowest level of the **uprights** by inserting the **barrel screws and bolts** as follows:
  - a. First through the hole in one end of the shelf piece,
  - b. Then through the lowest hole in the upright, and then
  - c. Through the hole in the other shelf.Connect the two shelf pieces surrounding the **upright** by inserting a **barrel screw and bolt**, making sure the **upright** is between the two shelves. You may **use** both hex wrenches to tighten this connection, but please, **do not fully tighten at this time.**  
**NOTE: You will be repeating the process of this instruction 3) with other seven shelf sets.**
- 4) Using the third shelf piece from the **shelf set** you are working with, repeat Step 3) to connect the two remaining open shelf pieces to the second **upright**.
- 5) Locate the third **upright**, make sure the marked lower end is to the right, and then connect this **upright** to the remaining two open shelf pieces with the barrel screws and bolts, as in Steps 3) and 4).
- 6) Locate another **shelf set**, move to the far left of your rack, and repeat steps 3)-5) to install the highest shelf layer into the "highest shelf set" position (see diagram) at the top of your cookware stand.
- 7) Your cookware stand can now be stood up, so you have the option of finishing assembly with the stand lying down or upright, whichever is the easiest for you and your partner to work from.
- 8) Repeat Steps 3) – 5) to connect the remaining **six shelf sets** to the three **uprights**.
- 9) Place the assembled rack upright on a level surface and using the two hex wrenches, tighten the **TOP** shelf first, then the **BOTTOM** shelf, then square up the stand and securely tighten all barrel screws and bolts on the remaining six shelves.
- 10) Apply the enclosed felt pads to the underside of the bottom tab of each of the three **uprights**.



## USE INSTRUCTIONS

- 1) Take care to place your cookware rack on a solid, level surface in an area out of the way from foot traffic.
- 2) Place heavier pots on the lower shelves and avoid over-loading top shelves to create a possible top-heavy condition and rack instability.

**WARNING:** It is important that your cookware stand is assembled correctly. If the unit is assembled or used incorrectly, it could become unstable and collapse, possibly causing injury.

**LIMITED WARRANTY:** This product is warranted to be free of material defects, other than that from normal use, for a period of five years from the date of purchase. Customer's exclusive remedy shall be the repair or replacement of the defective product and shall be subject to the following conditions: (1) notice of any defect is received by Enclume within the warranty period and (2) customer returns the defective product to Enclume Design Products, 24 Colwell St., Port Hadlock, WA 98339, postage prepaid within 20 days following a return authorization number (which may be obtained by telephoning the number at the top of this instructions) being provided to the customer by Enclume. There are no other warranties, expressed or implied. THERE ARE NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ENCLUME SPECIFICALLY DISCLAIMS ANY AND ALL INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE PURCHASE OR USE OF ENCLUME'S PRODUCTS.