


Modern Farmhouse TV Stand



Assembly Instructions

Product Dimensions:
47.24"L×15.75"D×15.75"H

Please take a moment to read through the entire instruction booklet before assembly to familiarize yourself with this product. Once you feel ready to start, follow the instructions step by step and this should make this process as easy as we could make it for you.

WARNING CAUTION

ADULT ASSEMBLY REQUIRED

CHOKING HAZARD

- This product includes small parts, sharp points and sharp edges in its unassembled state. Keep unassembled parts away from children under 3 years of age, and animals.

SAFETY WARNINGS

- Follow the information on the warnings appearing on table and on the carton. Do not remove warning label from cabinet.
- Do not allow children under 3 years of age to use the cabinet.
- Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.

FURNITURE TIP-OVER HAZARD

Children have died from furniture tip-over

To reduce the risk of furniture tip-over:

- ALWAYS install tip-over restraint especially if used by a wall or in the open.
- NEVER put a TV on this product
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- ALWAYS place heaviest items in lowest cabinet.

PARENTAL SUPERVISION IS REQUIRED

- Parents or Guardians should supervise use under the intended age specifically regarding children that may have access to it and climb on the unit.
- Do not allow horseplay on, under, or behind the unit and prohibit jumping on the cabinet.
- If used improperly, your table may be pulled over or fall, creating risk of injury or damage. Children should not be permitted to climb or pull on the cabinet.

USE, MAINTENANCE & ASSEMBLY

- Periodically check and ensure that the components are in their proper position, free from damage, and that all connectors are tight.
- Use on level surfaces only. Assemble on a soft level surface to avoid damage to unit or floor.
- Do not use this item if any components are missing or damaged.
- Do not use substitute parts. Contact the manufacturer or dealer for replacement parts.
- Only clean using damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- Check you have all components and tools listed on page 4
- Do not stand or put weight on this product during assembly, this could cause damage.
- Remove all hardware from the plastic bags and separate them into groups.
- Assemble the item as close to its final position (in the same room) as possible.
- Certain assembly steps may be easier with 2 people.
- Dispose of all packaging carefully and responsibly.
- We do not recommend power screwdrivers. Only use hand screwdrivers to prevent damage to unit.
- Keep these instructions for future reference.

Enfants morts suite au basculement d'un meuble.

Afin de limiter le risque de basculement de meuble:

- TOUJOURS utiliser les fixations anti-basculement.
- NE JAMAIS installer de TV sur ce produit.
- NE JAMAIS laisser d'enfants se tenir debout sur les tiroirs, portes ou étagères, y grimper ou s'y suspendre.
- NE JAMAIS ouvrir plus d'un tiroir à la fois.
- TOUJOURS placer les choses les plus lourdes dans les tiroirs du bas.


Han muerto niños por el vuelco de muebles.

Para limitar el riesgo de vuelco de los muebles:

- Utilizar SIEMPRE las fijaciones antivuelco que suministran.
- NUNCA instalar un TV sobre este producto.
- NUNCA permitir que los niños se pongan de pie, trepen o se cuelguen de los cajones, puertas o baldas.
- NUNCA abrir más de un cajón a la vez.
- Colocar los objetos más pesados en los cajones inferiores.

ASSEMBLY AT A GLANCE

Please take a moment to read through the whole instruction booklet before assembly to familiarize yourself with this product. Once you feel ready to start, follow the instructions step by step and this should make this process as easy as we could make it for you.




This drawing is to give you an overall idea only of how this assembly will go together and does not replace the assembly instructions.


COMPONENT PARTS

Please check that you have all the parts listed below

1. Top Panel ×1
2. Left Side Panel×1
3. Left Support Side Panel ×1
4. Right Support Side Panel×1
5. Right Side Panel×1
6. Drawer Panel ×2
7. Middle Panel×1
8. Drawer Left Support Panel ×1
9. Drawer Middle Support Panel ×2
10. Drawer Right Support Panel ×1
11. Drawer Middle Front Panel ×1
12. Bottom Panel ×1
13. Bottom Support Panel ×1
14. Bottom Support Panel×1
15. Bottom Left Support Panel ×1
16. Bottom Right Support Panel ×1
17. Drawer Door ×1
18. Back Panel ×3



ASSEMBLY HARDWARE



Tools Required



Phillips Screwdriver
(Medium) (not included)

***Do Not Use Power
Screwdriver or Drill.**




Hex Screwdriver
(included)

ASSEMBLY INSTRUCTIONS



1

Select C×4, E×4, and 3×1, 4×1, 7×1. Position 3 in the left, position 4 in the right. Insert 3 into the 7 with the C×2, E×2. Repeat the same steps for the 4.



2


Insert 8 into 2 with A×2, E×2. Insert B×2 into the 2. Repeat for the 5 and the 10.



ASSEMBLY INSTRUCTIONS


3

Select A×4, B×4, E×4, and 3×1, 4×1, 9×2. Insert 9 into 3 with A×2, E×2. Insert B×2 into the 3. Repeat for the 4 and 9.



4


Insert 15 into 13 with C×2. Repeat for the 13 and 16.



ASSEMBLY INSTRUCTIONS


5

Insert 14 into one side of the 15 with A×1, B×1 and E×1.
Repeat for the 14 and the 16.



6


Insert 2 into 11 with E×2.
Repeat for the 5 and 11.



ASSEMBLY INSTRUCTIONS


7

Select A×8, B×8, D×2, E×8 and 1×1. Insert 1 into the top of the 2, 3, 4, 5 and 11 with A×8, E×8, D×2. Insert B×2 into the 2. Repeat for the B×2 into the 3, 4, 5.



8


Select C×8, E×8 and 18×3. Install 18×3 into the groove of the 2 and 3, 3 and 4, 4 and 5. Insert 12 into the top of the 2, 3, 4 and 5 with C×8, E×8.



ASSEMBLY INSTRUCTIONS


9

Select A×10, B×10, E×8.
Insert Bottom Support Panel into the 12 with A×10, E×8 into the 2 and 5. Insert the B×2 into 16. Repeat for the 15. Insert B×3 into the 13. Repeat for the 14.



10


Insert H into the 11 into the 1 with the G×3.



ASSEMBLY INSTRUCTIONS


11

Insert K × 2 into the 3. Put the 6 × 1 onto the K × 2. Repeat for the 5 and 6.



12




Insert the J × 2 into the bottom of the 17.




ASSEMBLY INSTRUCTIONS

13

Insert Bottom of the 17 into the 12. Insert the F×4 into the 1×2 into the 17 into the 1.



ASSEMBLY COMPLETE



**CONGRATULATIONS, YOUR
MODERN FARMHOUSE TV STAND IS
COMPLETE!**