

ASSEMBLY INSTRUCTIONS


V-WD26-1365


PF021




WARNING !







Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.


Make sure no parts are missing or damaged before assembly.

PACKAGE CONTENT


Board Identification

Not actual size






X3




X4

BOARD IDENTIFICATION


Not actual size




① x4




② x1




③ x2




④ x7




⑤ x7




⑥ x4




⑦ x3




⑧ x3




⑨ x3




⑩ x4




⑪ x4




⑫ x4




⑬ x2



⑭ x1




⑮ x1




⑯ x1

BOARD IDENTIFICATION


Not actual size




17 x1




18 x1




19 x1




20 x1




21 x1



22 x1




23 x2




24 x1

HARDWARE LIST




A	x50+3




Ø15x9.5

B	x50+3




Ø6x30

C	64+3




Ø6x20

D	x2




Ø3.5x12

E	x98+3




Ø5x40

F	x20+2



Ø4x16

G	x4




Ø3x17

H	x6




Ø4x35


I	x32+3




J	x7



K	x2




L	x4




#10*15

M	x16+1



M6x35

N	x12+1




M6x20

O	x8




P	x2+2




Q	x1




CL	x7



CR	x7




DL	x7





DR	x7


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.











STEP 1

PF021



Ø3.5x12		CL		CR	
E	x 6	CL	x 1	CR	x 1


STEP 2





Ø3.5x12		CL		CR	
E	x 6	CL	x 1	CR	x 1

STEP 3


PF021















Ø3.5x12		CL		CR	
E	x 12	CL	x 2	CR	x 2

STEP 4










Ø3.5x12		CR		A	
E	x 9	CR	x 3	A	x 4

STEP 5

PF021




Ø3.5x12	
E	x 9

CL	
CL	x 3

A	
A	x 4

STEP 6





The panel gap faces upward.

Ø5x40	
F	x 2


STEP 7


PF021







STEP 8









Pay attention to the positions of the dowel holes and cam lock holes.




STEP 9


PF021








STEP 10








STEP 11


PF021



Ø6x30	
C	x 4

Ø5x40	
F	x 4

STEP 12




Ø6x30	
C	x 8

Ø5x40	
F	x 10

STEP 13


PF021



L	x 4

#10*15	
M	x 8

STEP 14 Note: Do not tighten the screws at this step.





Edges must be correctly oriented to avoid reverse installation.

#10*15	
M	x 8


STEP 15 Tighten all screws and bolts.

PF021







STEP 16




STEP 17

PF021






STEP 18





STEP 19


PF021



STEP 20








STEP 21


PF021



Ø6x30	
C	x 8

Ø15x9.5	
B	x 8


STEP 22




Ø3x17	
H	x 6


STEP 23

PF021






STEP 24





STEP 25


PF021




STEP 26











STEP 27

PF021



Ø3.5x12		DR		DL	
E	x 42	DR	x 7	DL	x 7


STEP 28




Ø3.5x12		J	
E	x14	J	x 7

STEP 29


PF021







STEP 30

PF021




STEP 31





STEP 32

PF021



bx2	ex2
K	

FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

· Tighten all bolts and screws again within the first 2 weeks of assembly
· Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

· Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
· Small amount of mild soap can be used if necessary
- **Dry the surface immediately after cleaning.**

⚠ DO NOT use bleach or alcohol detergent to clean the surface.
⚠ DO NOT apply wood treatment on parts made with MDF and PB.
Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.
Make sure to dry the furniture immediately after cleaning