


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY



DIFFICULT

Tools Required for Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(not Included)



2 PERSONS RECOMMENDED

Thank you for your purchase!


We hope you will enjoy your new product for many years to come. Our commitment to providing quality products does not simply end when a purchase is made. We stand behind our products and will provide any support needed in order for you to fully enjoy your purchase. Your satisfaction is the greatest recognition we could have.

Because we value your trust in our company, we will do our best to meet your service expectations. Should you have any assembly related questions, parts replacement requests, comments or suggestions, please feel free to contact us any time. To help expedite the service, please have the assembly instructions available, along with your order receipt.


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




1
When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




2
Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




3
Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



4
Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



5
Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




6
Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.










FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.










Before you begin, please read Page 3 of “Assembly and Care Advice”.

And remember, do not tighten until each step is completed or instructed.

Parts List

	#1 x 1 pc Headboard
	#2 x 2 pcs Headboard Leg
	#3 x 1 pc Footboard
	#4 x 1 pc Leg Support Rail
	#5 x 2 pcs Side Rail
	#6 x 3 pcs Slat
	#7 x 3 pcs Slat Support Leg

Hardware List


	#A x 6 pcs Bolt 5/16"x50mm
	#B x 2 pcs Bolt 5/16"x35mm
	#C x 8 pcs Lock Washer
	#D x 8 pcs Flat Washer
	#E x 1 pc Allen Wrench
	#F x 4 pcs Wood Dowel
	#G x 6 pcs Screw



Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling of the product and to avoid any potential injury and/or damage.



- #A x 6 pcs
- #B x 2 pcs
- #C x 8 pcs
- #D x 8 pcs
- #F x 4 pcs




Turn right (clockwise) to tighten

- With the help of another person, carefully place the headboard (#1) facing down on a protected surface.
- Insert 4 wood dowels (#F) into the leg support rail (#4).
- Align the two headboard legs (#2) with the wood dowels (#F) and the pre-drilled holes of the leg support rail (#4).
- Prepare 2 bolt assemblies by inserting FIRST the lock washer (#C) onto the bolt (#B) and then the flat washer (#D) onto the SAME bolt (#B), in that order.
- Insert the bolt assemblies through the leg support rail (#4) using the Allen wrench (#E) to lock them with the two headboard legs (#2).
- Align the assembled headboard legs (#2) with the pre-drilled holes of the headboard (#1).
- Prepare 6 bolt assemblies by inserting FIRST the lock washer (#C) onto the bolt (#A) and then the flat washer (#D) onto the SAME bolt (#A), in that order.
- Insert the bolt assemblies through the headboard legs (#2) using the Allen wrench (#E) to lock them with the headboard (#1).




- Insert the hooks of the two side rails (#5) into the slotted bars of the two headboard legs (#2). Make sure the parts are secured properly.
- Insert the hooks on the other ends of the two side rails (#5) into the slotted bars of the footboard (#3). Make sure the parts are secured properly.






- I. Align the threaded end of the slat support leg (#7) with the pre-drilled hole on the slat (#6) and tighten by hand until secured.
- II. Repeat the process above to assemble the remaining two slat support legs (#7) onto the two slats (#6).



#G x 6 pcs


- I. Align the ends of the assembled slat (#6) with the pre-drilled holes on each side of the side rails (#5).
- II. Secure two screws (#G) onto the ends of the slat (#6) by using a Phillips screwdriver to tighten them to the side rails (#5).
- III. Repeat the process above to assemble the remaining two assembled slats (#6) onto the side rails (#5).



Adjust the leveler according to the ground level. To lower or to raise the slat support leg, turn the leveler clockwise or counterclockwise, respectively.

ASSEMBLY IS COMPLETED

Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY



DIFFICULT

Tools Required for Assembly:

Allen Wrench



(Included)

Phillips Screwdriver



(not Included)



2 PERSONS RECOMMENDED

Thank you for your purchase!


We hope you will enjoy your new product for many years to come. Our commitment to providing quality products does not simply end when a purchase is made. We stand behind our products and will provide any support needed in order for you to fully enjoy your purchase. Your satisfaction is the greatest recognition we could have.

Because we value your trust in our company, we will do our best to meet your service expectations. Should you have any assembly related questions, parts replacement requests, comments or suggestions, please feel free to contact us any time. To help expedite the service, please have the assembly instructions available, along with your order receipt.


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.
PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.










Before you begin, please read Page 3 of “Assembly and Care Advice”.








And remember, do not tighten until each step is completed or instructed.

MD

Parts List

	#1 x 1 pc Headboard
	#2 x 2 pcs Headboard Leg
	#3 x 1 pc Footboard
	#4 x 1 pc Leg Support Rail
	#5 x 2 pcs Side Rail
	#6 x 4 pcs Slat
	#7 x 8 pcs Slat Support Leg

Hardware List


	#A x 6 pcs Bolt 5/16"x50mm
	#B x 2 pcs Bolt 5/16"x35mm
	#C x 8 pcs Lock Washer
	#D x 8 pcs Flat Washer
	#E x 1 pc Allen Wrench
	#F x 4 pcs Wood Dowel
	#G x 8 pcs Screw



Due to the size and/or weight of this product, it is highly recommended that the assembly should be done near the area of its intended location. Make sure you have enough space to move around during the assembly. ALWAYS have at least two people to help with transporting and assembling of the product and to avoid any potential injury and/or damage.



- #A x 6 pcs
- #B x 2 pcs
- #C x 8 pcs
- #D x 8 pcs
- #F x 4 pcs




Turn right (clockwise) to tighten

- With the help of another person, carefully place the headboard (#1) facing down on a protected surface.
- Insert 4 wood dowels (#F) into the leg support rail (#4).
- Align the two headboard legs (#2) with the wood dowels (#F) and the pre-drilled holes of the leg support rail (#4).
- Prepare 2 bolt assemblies by inserting FIRST the lock washer (#C) onto the bolt (#B) and then the flat washer (#D) onto the SAME bolt (#B), in that order.
- Insert the bolt assemblies through the leg support rail (#4) using the Allen wrench (#E) to lock them with the two headboard legs (#2).
- Align the assembled headboard legs (#2) with the pre-drilled holes of the headboard (#1).
- Prepare 6 bolt assemblies by inserting FIRST the lock washer (#C) onto the bolt (#A) and then the flat washer (#D) onto the SAME bolt (#A), in that order.
- Insert the bolt assemblies through the headboard legs (#2) using the Allen wrench (#E) to lock them with the headboard (#1).



- Insert the hooks of the two side rails (#5) into the slotted bars of the two headboard legs (#2). Make sure the parts are secured properly.
- Insert the hooks on the other ends of the two side rails (#5) into the slotted bars of the footboard (#3). Make sure the parts are secured properly.






#3

X4

- I. Align the threaded ends of the two slat support legs (#7) with the pre-drilled holes on the slat (#6) and tighten by hand until secured.
- II. Repeat the process above to assemble the remaining 6 slat support legs (#7) onto the 3 slats (#6).



Adjust the leveler according to the ground level on Step 4.


Turn right (clockwise) to tighten



#4

#G x 8 pcs

- I. Align the ends of the assembled slat (#6) with the pre-drilled holes on each side of the side rails (#5).
- II. Secure two screws (#G) into the ends of the slat (#6) by using a Phillips screwdriver to tighten them to the side rails (#4).
- III. Repeat the process above to assemble the remaining 3 assembled slats (#6) onto the side rails (#5).



Adjust the leveler according to the ground level. To lower or to raise the slat support leg, turn the leveler clockwise or counterclockwise, respectively.

ASSEMBLY IS COMPLETED