



TABLE OF CONTENT



----- P2-11



----- P12-21



----- P22-35


Before assembly, please confirm that these instructions match the model you purchased.

This manual may include instructions for multiple product variations.

For your safety:

- Keep children and pets away from the chair during assembly and operation.
- Ensure there are no obstacles around or underneath the chair mechanism.
- This product is not a toy. Use caution at all times to avoid injury.

Sofa



Note:

1. All necessary hardware is included. No additional tools are required for assembly. If you need assistance after receiving the product, please contact the seller with photos for reference.
2. This product is shipped in multiple boxes. All packages are shipped at the same time but may be delivered separately. Please allow additional time for all boxes to arrive.




! CAUTIONS

1. Make sure all slots and connections are fully and properly installed before use. Improper installation may result in product damage or personal injury.
2. Leave at least 0.5¹ inch of clearance between the back of the sofa and the wall before reclining. Insufficient clearance may damage the backrest.
3. Unplug the power cord from the electrical outlet before moving the sofa. Disconnect the power when the product is not in use.
4. Avoid prolonged exposure to direct sunlight to prevent material damage.

! WARNINGS

1. Keep all open flames and heat sources away from the sofa. Failure to do so may result in fire or serious damage.
2. Never stand or sit on the edge of the footrest or backrest while the sofa is reclined. Doing so may cause the sofa to tip over and result in serious injury.



Parts List

BOX-A					
Part	Description	Qty	Part	Description	Qty
A1		1pc	D1		1pc
BOX-B					
A2		1pc	D2		1pc
BOX-C					
B1		1pc	B2		1pc
C1		1pc	Box C also contains hardware and electrical components		
BOX-E					
C2		1pc			

This product is shipped in multiple boxes.
Please make sure all boxes are received before assembly.

Parts List

BOX-C

Part	Description	Qty	Part	Description	Qty
1		8pcs	2		4pcs
3		8pcs	4		2pcs
5		1pc	6		1pc
7		2pcs	8		2pcs
9		1pc			

Note: Remaining accessories in Box E


BOX C: Hardware and electrical components included in Box C.

This product is shipped in multiple boxes.


Please make sure all boxes are received before assembly.

Step 1

- Turn the base upside down.
- The power cord and LED light cable are secured with four cable ties for shipping purposes.
- Remove all four cable ties as shown to allow proper cable movement and prevent damage during operation.




Step 2



1. Align side backrest C1 with base A1, and slide it downward until it is fully seated.
2. Repeat the same process to install side backrest C2 onto base A2.
3. Make sure both side backrests are securely installed before proceeding.


Step 3



Assembly Instructions

1. Install side panels D1 and D2 first, making sure they are securely positioned.
2. Align the backrests (B1, and B2) with the corresponding slots on the bases (A1, and A2).
3. Insert each backrest straight down into the slot until it is fully seated.
4. You will hear a *click* when the backrest is properly locked in place.


Step 4



Note:

Part 5 is used to secure connector plate Part 4 to the base frame
Use connector plates (Part 4) to connect bases A1 and A2 as shown.
Insert the screws and hardware in the order illustrated, but do not fully tighten them.
Leave the screws slightly loose to allow for proper alignment.
Fully tighten all screws after the entire installation is complete.

Step 5



Accessories Included: Part 6× 1 Part 7× 2 Part 8× 2 Part 9× 1

Backrest Cable Connections:


The backrest has four cables. After the backrest is fully inserted into the base, make the following connections:

1. Connect the red cable from the backrest to the red cable located at the rear of the base, near the backrest.
2. Connect the white cable from the backrest to the white cable located at the rear of the base, near the backrest.
3. Connect the two black cables from the backrest separately to: Part 7 (massage controller), Part 8 (massage/heating adapter)

Base Cable Connections:

After completing the backrest cable connections, three cables remain at the bottom of the base. Connect them as follows:

1. Connect the motor control cable to the armrest control switch.
2. Connect the LED light cable to the armrest LED port.
3. Connect the motor power control cable to Part 9, then connect Part 9 to the motor adapter (Part 6) and plug it into a wall outlet.



Button function description

1. **USB INTERFACE:** Supports USB interface fast charging

2.**Type-C INTERFACE:** Support for Type-C interface fast charging

3.**Light "ON/OFF":**

① Long press 2S, light belt on, default breathing mode;

4. **LIGHT BRIGHTNESS ADJUSTMENT:**

Provide two brightness choices, the switch button is visible light light and dark changes

5. **LIGHT MODE SELECTION:**

Provide five light mode selection, switch the button to select the light effect, the default breathing mode

6. **BACKREST DOWN:**


Long press push rod continues to drop, loosen that stop, short press can be adjusted

7. **BACKREST UP**

Long press push rod continues to rise, release that stop, short press can be adjusted

remarks: 1. The push rod work is not synchronized with the charging, that is, the push rod works, the fast charging temporarily stops charging, the push rod stops, and the fast charging immediately resumes charging


Functional instruction



Note:

1. When the massage function is turned on, all massage zones may activate by default. You can manually select your preferred zones using the controller.
2. For safety, the massage and heating functions will automatically shut off after 15 minutes. To continue use, simply restart the function and select the desired time setting.





Sofa



Note:

1. All necessary hardware is included. No additional tools are required for assembly. If you need assistance after receiving the product, please contact the seller with photos for reference.
2. This product is shipped in multiple boxes. All packages are shipped at the same time but may be delivered separately. Please allow additional time for all boxes to arrive.


Parts List

BOX-A					
Part	Description	Qty	Part	Description	Qty
A1		1pc	D1		1pc
BOX-B					
A2		1pc	D2		1pc
BOX-C					
B1		1pc	B2		1pc
C1		1pc	Box C also contains hardware and electrical components		
BOX-D					
F		1pc	E		1pc
C2		1pc	1		8pcs
2		4pcs	4		2pcs

This product is shipped in multiple boxes.
Please make sure all boxes are received before assembly.

Parts List

BOX-C

Part	Description	Qty	Part	Description	Qty
1		8pcs	2		4pcs
3		8pcs	4		2pcs
5		1pc	6		1pc
7		2pcs	8		2pcs
9		1pc			

Note: Remaining accessories in Box D


BOX C: Hardware and electrical components included in Box C.

This product is shipped in multiple boxes.


Please make sure all boxes are received before assembly.

Step 1

- Turn the base upside down.
- The power cord and LED light cable are secured with four cable ties for shipping purposes.
- Remove all four cable ties as shown to allow proper cable movement and prevent damage during operation.



Step 2



Hardware Required: Part 1× 8 Part 2× 4 Part 3× 8 Part 4× 4 Part 5× 1

Note:

Part 5 is used to secure connector plate Part 4 to the base frame


Use connector plates (Part 4) to connect bases A1 and A2 as shown.

Insert the screws and hardware in the order illustrated, but do not fully tighten them.

Leave the screws slightly loose to allow for proper alignment.


Fully tighten all screws after the entire installation is complete.

Step 3



1. Align side backrest C1 with base A1, and slide it downward until it is fully seated.
2. Repeat the same process to install side backrest C2 onto base A2.
3. Make sure both side backrests are securely installed before proceeding.


Step 4



Assembly Instructions

1. Install side panels D1 and D2 first, making sure they are securely positioned.
2. Align the backrests (B1, E, and B2) with the corresponding slots on the bases (A1, F, and A2).
3. Insert each backrest straight down into the slot until it is fully seated.
4. You will hear a *click* when the backrest is properly locked in place.

Step 5



Accessories Included 2" Part 6× 1 Part 7× 2 Part 8× 2 Part 9× 1

Backrest Cable Connections:


The backrest has four cables. After the backrest is fully inserted into the base, make the following connections:

1. Connect the red cable from the backrest to the red cable located at the rear of the base, near the backrest.
2. Connect the white cable from the backrest to the white cable located at the rear of the base, near the backrest.
3. Connect the two black cables from the backrest separately to: Part 7 (massage controller), Part 8 (massage/heating adapter)

Base Cable Connections:

After completing the backrest cable connections, three cables remain at the bottom of the base. Connect them as follows:

1. Connect the motor control cable to the armrest control switch.
2. Connect the LED light cable to the armrest LED port.
3. Connect the motor power control cable to Part 9, then connect Part 9 to the motor adapter (Part 6) and plug it into a wall outlet.



Electrical Specifications:

Input Voltage: 110V-240V AC

Input Current: 10A-16A

Frequency: 50/60Hz

USB Output:

·USB-A:5V-3A,9V-2A,12V-1.5A

·USB-C:5V-3A,9V-2.22A,12V-1.67A


Power Cord:14/16/18 AWG

Safety Information

1. Do not expose this product to water or moisture. For indoor use only.
2. This product is ETL/UL certified. Use only in a dry, indoor residential environment.

Safety Notes:

- This product contains electrical components. Do not expose to high temperatures or humidity.
- Always unplug the product when not in use.
- Plug into a properly grounded wall outlet only.
- Do not use extension cords or plug adapters.
- Do not modify the plug or power cord.
- Do not allow unattended children or individuals with physical or cognitive impairments to use this product.



Button function description

1. **USB INTERFACE:** Supports USB interface fast charging

2.**Type-C INTERFACE:** Support for Type-C interface fast charging

3.**Light "ON/OFF":**

① Long press 2S, light belt on, default breathing mode;

4. **LIGHT BRIGHTNESS ADJUSTMENT:**

Provide two brightness choices, the switch button is visible light light and dark changes

5. **LIGHT MODE SELECTION:**

Provide five light mode selection, switch the button to select the light effect, the default breathing mode

6. **BACKREST DOWN:**


Long press push rod continues to drop, loosen that stop, short press can be adjusted

7. **BACKREST UP**

Long press push rod continues to rise, release that stop, short press can be adjusted

remarks: 1. The push rod work is not synchronized with the charging, that is, the push rod works, the fast charging temporarily stops charging, the push rod stops, and the fast charging immediately resumes charging


Functional instruction



Note:

1. When the massage function is turned on, all massage zones may activate by default. You can manually select your preferred zones using the controller.
2. For safety, the massage and heating functions will automatically shut off after 15 minutes. To continue use, simply restart the function and select the desired time setting.








Sofa



Note:



1. All necessary hardware is included. No additional tools are required for assembly. If you need assistance after receiving the product, please contact the seller with photos for reference.
2. This product is shipped in multiple boxes. All packages are shipped at the same time but may be delivered separately. Please allow additional time for all boxes to arrive.

Parts List

BOX-A					
Part	Description	Qty	Part	Description	Qty
A1		1pc	D1		1pc
BOX-B					
A2		1pc	D2		1pc
BOX-C					
B1		1pc	B2		1pc
C1		1pc	Box C also contains hardware and electrical components		
BOX-E					
C2		1pc			
BOX-F					
G		1pc	H		1pc
1		8pcs	2		4pcs
4		2pcs			

This product is shipped in multiple boxes.
Please make sure all boxes are received before assembly.

Parts List

BOX-C					
Part	Description	Qty	Part	Description	Qty
1		8pcs	2		4pcs
3		8pcs	4		2pcs
5		1pc	6		1pc
7		2pcs	8		2pcs
9		1pc			

Note: Remaining accessories in Box F


BOX C: Hardware and electrical components included in Box C.

This product is shipped in multiple boxes.


Please make sure all boxes are received before assembly.

Step 1

- Turn the base upside down.
- The power cord and LED light cable are secured with four cable ties for shipping purposes.
- Remove all four cable ties as shown to allow proper cable movement and prevent damage during operation.



Step 2



Hardware Required: Part 1× 8 Part 2× 4 Part 3× 8 Part 4× 4 Part 5× 1

Note:

Part 5 is used to secure connector plate Part 4 to the base frame


Use connector plates (Part 4) to connect bases A1 and A2 as shown.

Insert the screws and hardware in the order illustrated, but do not fully tighten them.

Leave the screws slightly loose to allow for proper alignment.


Fully tighten all screws after the entire installation is complete.

Step 3



1. Align side backrest C1 with base A1, and slide it downward until it is fully seated.
2. Repeat the same process to install side backrest C2 onto base A2.
3. Make sure both side backrests are securely installed before proceeding.


Step 4



Assembly Instructions

1. Install side panels D1 and D2 first, making sure they are securely positioned.
2. Align the backrests (B1, G, and B2) with the corresponding slots on the bases (A1, H, and A2).
3. Insert each backrest straight down into the slot until it is fully seated.
4. You will hear a *click*— when the backrest is properly locked in place.

Step 6



Accessories Included 1 Part 6× 1 Part 7× 2 Part 8× 2 Part 9× 1

Backrest Cable Connections:

The backrest has four cables. After the backrest is fully inserted into the base, make the following connections:


1. Connect the red cable from the backrest to the red cable located at the rear of the base, near the backrest.
2. Connect the white cable from the backrest to the white cable located at the rear of the base, near the backrest.
3. Connect the two black cables from the backrest separately to: Part 7 (massage controller), Part 8 (massage/heating adapter)

Base Cable Connections:

After completing the backrest cable connections, three cables remain at the bottom of the base. Connect them as follows:

1. Connect the motor control cable to the armrest control switch.
2. Connect the LED light cable to the armrest LED port.
3. Connect the motor power control cable to Part 9, then connect Part 9 to the motor adapter (Part 6) and plug it into a wall outlet.

Step 7



Electrical Specifications:

Input Voltage: 110V~240V AC

Input Current: 10A~16A

Frequency: 50/60Hz

USB Output:

·USB-A:5V-3A,9V-2A,12V-1.5A·

USB-C:5V-3A,9V-2.22A,12V-1.67A

Power Cord:14/16/18 AWG



Safety Information


1. Do not expose this product to water or moisture. For indoor use only.
2. This product is ETL/UL certified. Use only in a dry, indoor residential environment.

Safety Notes:

· This product contains electrical components.

Do not expose to high temperatures or humidity.

- Always unplug the product when not in use.
- Plug into a properly grounded wall outlet only.
- Do not use extension cords or plug adapters.
- Do not modify the plug or power cord.
- Do not allow unattended children or individuals with physical or cognitive impairments to use this product.



Button function description

1. **USB INTERFACE:** Supports USB interface fast charging

2.**Type-C INTERFACE:** Support for Type-C interface fast charging

3.**Light "ON/OFF":**

① Long press 2S, light belt on, default breathing mode;

4. **LIGHT BRIGHTNESS ADJUSTMENT:**

Provide two brightness choices, the switch button is visible light light and dark changes

5. **LIGHT MODE SELECTION:**

Provide five light mode selection, switch the button to select the light effect, the default breathing mode

6. **BACKREST DOWN:**


Long press push rod continues to drop, loosen that stop, short press can be adjusted

7. **BACKREST UP**

Long press push rod continues to rise, release that stop, short press can be adjusted

remarks: 1. The push rod work is not synchronized with the charging, that is, the push rod works, the fast charging temporarily stops charging, the push rod stops, and the fast charging immediately resumes charging

Functional instruction



Note:

1. When the massage function is turned on, all massage zones may activate by default. You can manually select your preferred zones using the controller.
2. For safety, the massage and heating functions will automatically shut off after 15 minutes. To continue use, simply restart the function and select the desired time setting.

WARRANTY & CUSTOMER SUPPORT

All products are carefully inspected before shipment to ensure quality and performance.

If you notice any damage or quality issues after receiving the product, please contact us promptly. Our after-sales support team will assist you as quickly as possible.

For faster service, please provide:

- A brief description of the issue
- Clear photos of the issue and overall product
- The part number shown in the instruction manual

This information helps us identify the affected part and provide an effective solution.

AFTER-SALES SERVICE POLICY

Warranty Service

During the warranty period, we offer replacement parts or appropriate solutions for product quality issues.

For functional or operational issues, we may guide you through simple troubleshooting steps to help determine the cause and resolve the problem efficiently.

Returns

If you are not satisfied with the product, please contact us within 3 days of receiving it.

Approved returns must be sent back in original condition and packaging to qualify for a refund.

Warning

Do not sit or apply pressure on the armrests.




Do not apply pressure to the backrest while reclining.




Do not exit the chair while it is reclining.




Do not sit, stand, or place weight on the footrest when it is raised.



Allow clearance between the chair and the wall before reclining.



Do not lean excessively backward.



Two-person lift required.



Do not move the chair while it is reclining.

