



RP104226
1.2 PGM (4.5 L/min)
Aerator
Aireador
Aérateur




RP104229▲
Gasket
Empaque
Joint




RP102074
Bracket & Nut
Abrazadera y
Ensamble de
Tuerca
Support et Écrou


RP100766▲
Push Pop-UP with Overflow
Control de rebose para
desagües manuales
Mécanique à pousser avec trop-plein






RP101333
Quick Connector
Adaptador Conexión Rápida
Raccord Rapide



RP104228▲
Handle Assemblies
Conjunto de manija
Montage de la manette



RP101069
Stem Unit Assembly, Seat & Spring,
Bonnet Nut
Ensamble de la Unidad del Vástago,
Asiento, Resorte y Bonete
Obturbateur, siège et ressort et écrou à
chapeau



RP101297
Washers (2), Nuts (2)
& Screws (4)
Arandelas (2), Tuercas (2)
y Tornillos (4)
Rondelles (2), Écrous (2)
et Vis (4)