


Assembly Instruction Sheet for Model HL783173

Package Contents

Part	Description	Quantity
A	Mounting Bracket	1 pc.
B	Fixture Body	1 pc.
C	Fabric Shade	1 pc.
D	Hanging Rod	1 pc.
E	Ceiling Canopy	1 pc.



STEP 1

Mark the drilling position on ceiling with the help of the Mounting Bracket(A).
Drill holes on the marks and stick the expansion anchors into the holes.
Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

STEP 2

Thread the wire of Fixture Body(B) through the Fabric Shade(C) and the Hanging Rod(D),
and twist fix the Hanging Rod(D) to the Fabric Shade(C).

STEP 3

Thread the wire from the Hanging Rod(D) to the hole of Ceiling Canopy(E),
and fix the Hanging Rod to the Ceiling Canopy(E) with a washer and nut.

STEP 4

Hold the fixture close to the ceiling.
Connect live line to wire color Black/Red from the Ceiling Canopy(E).
Connect neutral line to wire color White/Blue from the Ceiling Canopy(E).

STEP 5

Attach the Ceiling Canopy(E) to the Mounting Bracket(A).

STEP 6

Insert your bulb into the bulb base.

Your fixture is now assembled and ready to use.