











IF YOU BUY A SINGLE ARMLESS SOFA
please follow below assembly instruction



Parts List (Box 1)

C Middle seat frame  1PC	E Middle back cushion  1PC	F Leg  4PCS
H Backrest  1PC	J Pillow  1PC	N Middle seat cushion  1PC
Q Middle seat frame cover  1PC	K Connector  2PCS	R M8X60MM Bolt  4PCS
T Washer  4PCS	U Allen key  1PC	


Note: Please retain all boxes until you are certain that your product isn't damaged and that you do not wish to return it. Disposal of boxes may prevent our ability to resolve your request.

ASSEMBLY STEPS


STEP 1 Assemble the Legs (F) to the Middle seat frame (C).




STEP 2 Insert the Middle seat frame cover (Q) into the Middle seat frame (C).




STEP 3 Insert the Backrest (H) into the designated holes, using Washers (T) and Bolts (R) to 70% tightness, and then tighten all bolts on the seat.



STEP 4 The cushion is packed by vacuum compression. After cutting the package, it rebounds quickly within 4 hours. If the fabric has wrinkles, it will basically disappear after standing for 72 hours. If still has wrinkles after 72 hours, steam with iron is workable.



STEP 5 Put Middle seat cushion (N), Middle back cushion (E) and Pillow (J) to the Sofa.



STEP 6 Completed.

