
# **INSTALLATION MANUAL**



#### **Installation Manual**

#### **General Guidelines**

- Please read the following instructions carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed

#### **Notes:**


- The product must be assembled and used by the provisions of the manual. The seller does not assume any
  responsibility or liability concerning any damage caused by incorrect assembly or improper use.
- It is recommended that assembly is undertaken by at least 2 adults and an electric drill is prepared to facilitate the assembly. Please read assembly instructions before assembly and strictly adhere to each step outlined.
- If there is/are defective and/or missing part/s after unpacking, please cease assembly immediately and get in contact with us.
- Please assemble the item in a spacious room and do not place the unwrapped product directly on the ground to avoid damage.
- Please be careful during the assembly to avoid scratches from any sharp edges.
- Please match the corresponding board and fitting based on the part number in the manual.
- If the board does not match with the fitting, please check the pieces as specified in this manual.
- Please refer to the diagram during assembly. Align and hand tighten all screws in their associated pre-drilled holes first before tightening each screw.
- Peals do not over tighten connectors (screws, bolts, etc). Over-tightening can lead to product damage.
- Periodically inspect screw tightness while the product is in use. If necessary, retighten to ensure structural integrity.

#### **Warnings**

- It is not intended for use by children under 3 years of age. Children must be under adult supervision to use the product.
- It is forbidden for children to climb or play on the product to avoid serious body injury caused by the toppling.
   During the assembly process, keep any small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (films, plastic bags and foam, etc.) away from babies and children.


### **Packing Lists**

Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact us to obtain any missing parts.





The bottom panel ⑥ and the top panel ⑦ are close in appearance, but the positioning of the screw holes is different. Please pay attention to the distinction and do not install the opposite.



### **Accessories**



Two in one screw \* 32



**f** Door hinge \* 2



**b** Eccentric gear \* 32



g Handle \* 1



**d** Tapping screw \* 12




h Expansion screw \* 2





*B* Wooden pole \* 4


#### **Tools Required**















1

Install the Two in one screw, Wooden pole and Eccentric gear on Workpiece  $\@3$  to  $\@3$ .











### 2

Connect 2 to 3 ,1 to 3.



3

Install 4 to 123 Consolidated components.






 $\triangle$ 


The grooved side is the back side of 4, which must be oriented in the same direction as part of the 123component.

4


Install 8 and 9 on 4.

















Insert back panel (10) and (11).







8 Install the Top panel 7 .




9 Install the door hinge.









#### Install the door hinge and the handle.





#### [ Sketeh Map For Adjusting Cabinet Door In Three Dimensions ]




Front and rear adjustment in three dimensions. The clearance between door board and cabinet side board can be changed only by adjusting screw "A"

Adjustable screw "B" Left and right adjustment in three dimensions Vertical adjustment in three dimensions Verticality and clearance between top and bottom can be comected by adjusting screw "C" on hinge base board.



Determine the desired mounting location, Fix the Wall Cleat on the wall and install the cabinet.



#### **Care and Maintenance**

- Cleaning with a dry cloth may be sufficient.
- For other stains or marks, wipe gently with a damp cloth.
- Do not use strong detergents or abrasive cleaners; they may damage the surface of the cabinet.
- As the product is sealed during transportation, please open the cabinet for several days after receiving the goods to ventilate the smell.