























Please read these instructions and warranty information carefully before use and keep them properly for future reference.


ASSEMBLY INSTRUCTION

PARTS										
A	1				Q	2				
B	1				R	2				
C	1				S	2				
D	1				T	2				
E	2				U	1				
F	2									
G	1				V ₁	1				
H	4				V ₂	1				
I	1				W	4				
J	1				X1	6	 M8X50			
K	1				X2	12	 M6X20			
L	2				X3	4	 M6X30			
					X4	8	 M6X35			
M	2	Right	1		X5	4	 M8X50			
		Left	1		X6	8	 M6X45			
N	1				Z	40	 M8			
					Z1	2				
O	1				Y	4				
					AA	1				
P	4				BB	1				
						1				







3




5




4




6




7



9



8



10