Instruction for Remote Control:

| | Light ON ← | ☼ ON | ☀ OFF | → Light OFF |
Color(warm) ←	◀《K》	《K》▶	→ Color(cool)
Brightening ←	☼ +	☼ −	→ Dimming
Night Mode ←	☾	《K》	→ Color Shifting
S.light(optional) ←	S.light	⏰	→ Timing(60mins)

1. The button with MOON PATTERN represents "Night Mode" feature,which is able to reset the brightness and color of the lamp to default.

2. Push the timing button, if the lamp flashes two times in a row,it indicates that 60mins timing function has been initiated.

3. Code pairing should be performed before using the remote when it is unable to control the light, please complete the following steps below:

   ①.Power on the lamp and press the "ON" button of the remote("ON" button should be pressed within 3 seconds after the lamp turned on).

   ②.If the light flashes 3 times after step 1, it indicates that the remote is successfully paired with the lamp.

   For more details please check remote control instruction.
   Note:Please ensure that the FOOT SWITCH is ON before use remote control.

Assembly Instruction:

Insert the DC power cable with each other accurately and tighten.

1. Insert the power plug into the DC connecter hole.

2. Rotary plug to fix power cables.

After insert the DC power cable, twist the floor lamp body clockwise onto the lamp pole and tighten.

Power adapter

Foot switch

Twist the floor lamp pole clockwise onto the lamp base and tighten.

Note: 1. All operations must be performed only after switching off or powering off.

2. It is normal that yellow light spots appear from the light strip after brightness is adjusted to the minimum.

3. The minimum brightness is not equal to 0% brightness.

4. The lampshade may be slightly separated during transportation, which results in light leakage, it can be easily fixed by pushing it gently by hand.