



ASSEMBLY INSTRUCTIONS *COASTER FINE FURNITURE*



Fine Furniture for every stage of life

102554 **Adjustable Bar Chair**

REVISION 0: 06/16/2020
REVISION 1: 08/04/2022
REVISION 2: 11/29/2024
REVISION 3: 06/30/2026

COASTERFURNITURE.COM

ITEM: 102554



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

AV SEAT AND BACK




1PC

BV FOOTREST



1PC

CV GAS LIFT



1PC

DV BASE



1PC

HARDWARE IDENTIFICATION

1 BOLT
(Ø1/4 x 15mm - SR)



4PCS

2 LOCK WASHER
(Ø1/4" x 12mm - SR)



4PCS

3 FLAT WASHER
(Ø1/4" x 16mm - SR)



4PCS

4 ALLEN WRENCH
(M5 x 59mm - SR)



1PC

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **102554**


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




* BOTTOM VIEW


STEP 3



STEP 4 **COMPLETE**



ITEM: **102554**



Note: Dimension tolerance $\pm 5\%$