

58" Dancing Santa w/ Teddy Bear & Toy Sack



I saw mommy dancing with Santa Claus!
Our dancing Santa, we will have everyone
dancing and spreading holiday cheer.

Standing 58 inches tall, Santa carries a
teddy bear and a toy sack filled with holiday
goodies. When motion is detected, he will
move his arms and sway his body to the
song Jingle Bell Rock.

Dressed in his traditional red and white suit,
his friendly face with open spectacles, round
chubby cheeks, and soft full beard will warm
your heart. Place him in the foyer, near the
fireplace, or next to the family Christmas
tree, and watch as everyone starts dancing!

- Motion-activated dancing Santa with music
- Motion sensor triggered from 1.5 to 5 feet
- Music speaker and volume knob located on base
- Enjoy animation without music via switch on base
- Recommended for indoor use only
- Assembly required - Collapsible for easy storage
- 1-year warranty

Model Number	UPC	Dimensions	Description
		15" D x 21" W x 58" H	Dancing Santa w/ Teddy Bear & Toy Sack