















Assembly Instructions

| | | | | | | |
|-------|---|---|---|--|---|---|
| parts | Ax5 | Bx1 | Cx1 | Dx1 | Ex1 | Fx1 |
| |  |  |  |  |  |  |
| | Gx8 | Hx4 | Ix2 | Jx8 | Kx1 | Lx1 |
| |  |  |  |  |  |  |
| | M6x1" | M8x1" | | | | |


1



2



3



4

