









IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

ASSEMBLY & INSTRUCTION MANUAL

PARTS




HARDWARE



01

A x 1

F x 1




A



F


x4

02




B x 2


C x 2



E x 4




A x 4




B x 2

C x 2




B x 2

C x 2




B x 2

C x 2




B x 2

C x 2



D x 5



G x 2
M4*50

H x 2
M4

I x 2

